MINEX II

Performance of Fingerprint Match-on-Card Algorithms Phase II / III Report

NIST Interagency Report 7477

(Revision I)

P. Grother, W. Salamon, C. Watson, M. Indovina, and P. Flanagan

Information Access Division National Institute of Standards and Technology



Executive Summary

The MINEX II trial was conducted to evaluate the accuracy and speed of MATCH-ON-CARD verification algorithms. These run on ISO/IEC 7816 smartcards. They compare conformant reference and verification instances of the ISO/IEC 19794-2 COMPACT CARD fingerprint minutia standard. The test is an assessment of the core viability of matching fingerprints (i.e. the de facto leading compact biometric data element) on personal identity credentials based on the industry-standard smart cards. The results are relevant to users seeking to use minutia templates as an additional factor for authentication.

MINEX II did not evaluate interface standards, secure transmission protocols, nor card or algorithm vulnerabilities. In addition it did not mimic a particular verification scenario, and it did not compare fingerprint sensors or system-on-card implementations. More generally an exposition of the advantages and disadvantages of MATCH-ON-CARD is beyond the scope of this report. Also out-of-scope is consideration of modalities beyond fingerprints[4].

This document is a revised version of the first MINEX II report published on February 29, 2008¹. This revision includes results for seven new MATCH-ON-CARD implementations submitted to NIST by four teams in late 2008.

This document defines interoperability in terms of the biometric matching error rates measured when a matching algorithm from company X compares two standard records produced by the fingerprint minutia extraction algorithms of companies Y and Z. An interoperable MATCH-ON-CARD implementation is one that gives low error rates irrespective of the producer of the input records.

The significant results of the test follow below.

	The most interoperable MATCH-ON-CARD implementation achieves the minimum error rate speci- fications of the United States' Government's PIV program. A second MATCH-ON-CARD implemen- tation achieves the PIV accuracy specifications. Two other implementations would attain this level but for degraded performance associated with the templates from a third party minutia template generator.	Sec. 4.4
⊳	The most interoperable MATCH-ON-CARD implementation executes 50% of genuine ISO/IEC 7816 VERIFY commands in 0.54 seconds or less (i.e. median), and 99% within 0.86 seconds. The second PIV-compliant implementation executes 50% of genuine comparisons in under 0.28 seconds.	Sec. 5
⊳	By submitting multiple implementations, three MINEX II participants have demonstrated an ability to tradeoff accuracy for speed. Improved accuracy may be available if speed can be sacrificed.	Sec. 5
	For the providers who have submitted both MATCH-ON-CARD and MATCH-OFF-CARD minutiae matching algorithms to NIST, the accuracy only approaches that of the off-card siblings. For the most interoperable implementation there are around five false rejection errors ON-CARD for every four OFF-CARD. This lag is not attributable to the ISO/IEC 19794-2 COMPACT CARD format. For any given pair of template generators, MATCH-ON-CARD algorithms do not give the same accuracy as the MATCH-OFF-CARD implementation from the same supplier.	Sec. 4.2
⊳	False non-match errors, at the industry-preferred false match rate (FMR) of 0.0001 , are from two to four times more frequent than at FMR = 0.01 .	Sec. 4.4
⊳	As in MINEX04[8], the use of two fingers greatly improves accuracy. Using OR-rule fusion at a fixed operating threshold, the effect of using a second finger only after a rejection of the first, is to reduce false rejection while increasing false acceptance.	Sec. 4.6
⊳	Using OR-rule fusion with the most interoperable implementation, and targeting $FMR = 0.001$, it is necessary to employ the second finger for fewer than 4% of genuine users.	Sec. 4.7

¹The original report is archived at http://fingerprint.nist.gov/minexII/minex_report1.pdf.

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

- Some MATCH-ON-CARD implementations emit only a few unique matcher scores. This precludes Sec. 4.8 \triangleright fine-grained setting of the operating threshold. This disadvantages those implementations because overly conservative FMR values give rise to elevated FNMR. The late 2008 implementations produce many more unique matcher scores than in late 2007. This increase allows users to more finely target false match rates. Some cards indicated a capability to accept no more than 55 minutiae, and this necessitates removal \triangleright Sec. 4.9 of minutiae from either or both of the reference and verification templates prior to transmission to the card in 16.5 % of genuine comparisons. The use of one implementation's minutia quality values for removal is superior to using radial distance alone. MINEX II attained unprecedented transparency in its execution: the evaluation plan was published Sec. 3.5 ⊳ during its development with industry, and version-controlled open-source software was released for both conformance and conversion of INCITS 378 and ISO/IEC 19794-2 COMPACT CARD templates^{*a*}, and for invocation of ISO/IEC 7816 MATCH-ON-CARD operations. ^aThese standards are available from http://webstore.ansi.org. The MINEX II evaluation will continue in the second half of 2009 as Phase IV. This is intended to ⊳ gauge improvements over existing implementations and to evaluate new teams. After inviting comment in March 2008, NIST received no input on whether to evaluate the use of proprietary templates for MATCH-ON-CARD, and is unlikely to pursue testing thereof. ⊳ NIST does invite comment on how minutia interoperability can be improved, and specifically how NIST can support that objective. This applies to both ON-CARD and OFF-CARD paradigms. Comments and inquiries are welcome via MINEXII@NIST.GOV. \triangleright
- Generally biometric test reports are relevant only within a particular context, and therefore a number of caveats apply to the quantitative results and conclusions of this report.
- ▷ The authors are available to talk about this report.

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

Caveats

As with all biometric evaluations, the results of this test must be carefully interpreted before any predictive conclusions can be made. Users should factor the following into policy, planning and operational decisions.

- 1. The absolute error rates quoted herein were measured by using the provided implementations on a very large fixed corpus of operational fingerprint images. However, error rates observed in real-world applications are strongly dependent on a number of factors legitimately not reflected in the experimental design of MINEX II. Among these are:
 - ▷ Environment For instance, low humidity is associated with higher false rejection;
 - ▷ Number of verification attempts More attempts lead to lower false rejection, and higher false acceptance;
 - Number of images used, and the fusion policy If several images from a sequence are matched, accuracy can be improved;
 - ▷ Number of fingers used, and the fusion policy If images from two or more fingers are used, accuracy is improved;
 - ▷ Demographics Younger adult populations are widely considered to be easier to match;
 - ▷ Habituation Users who regularly interact with a system experience lower rejection rates;
 - ▷ The sensor, and the enrollment policy The application of quantitative quality criteria, e.g. in an auto-capture loop, improves error rates;
 - ▷ The data format in use Proprietary templates generally offer superior error rates to standardized formats[8], but are non-interoperable. Proprietary extensions to standard templates are similarly non-interoperable unless executable code for each vendor's extensions is built into the reader or read from the card.
- 2. With respect to MOC specifically, the accuracy and speed of operational verification transactions will generally depend on a number of factors, including the following.
 - > The operational card stock in use.
 - ▷ The number of templates stored on the card.
 - ▷ The number of fingers presented.
 - ▷ The quality of the enrollment procedure, particularly whether a verification was done at time of card issuance.
 - ▷ The communications channel and interface.
 - ▷ The cryptographic operations needed to secure the channel and to authenticate the card and data elements (but see SBMOC in section 1.4).

In addition, the template generation and matching algorithms are strongly influential on error rates. To the extent that MINEX II measured the accuracy of leading industrial and academic algorithms (i.e. only partially), these aspects are documented here. Thus this MINEX trial addresses the core algorithmic capability of a MOC implementation. The results:

- ▷ support qualification processes (e.g. PIV),
- ▷ have relevance operationally (matching accuracy and speed are strongly *influential* components of a system),
- ▷ are not sufficient for prediction of fielded performance.

Disclaimer

Specific hardware and software products identified in this report were used in order to perform the evaluations described in this document. In no case does identification of any commercial product, trade name, or vendor, imply recommendation or endorsement by the National Institute of Standards and Technology, nor does it imply that the products and equipment identified are necessarily the best available for the purpose.

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

Release Notes

- The MINEX II evaluation was conducted in accordance with the MINEX II Specification which has been released as a separate NIST Interagency Report, NISTIR 7485[9]. The plan was developed by NIST in consultation with members of the fingerprint and smart card industries, and the general public. The document was drafted in April 2007, and finalized on August 15, 2007. The new NISTIR version adds only a note on context, a coversheet, and acknowledgements to it. It is being referred to here because the document is cited herein, and because it is a suitable protocol for other organizations wishing to evaluate MATCH-ON-CARD implementations.
- Since late 2008 the MINEX II Specification has formed the basis for a formal standard for testing of MATCH-ON-CARD performance. The draft standard is ISO/IEC CD 19795 - Biometric Performance Testing and Reporting -Part 7: Testing of ISO/IEC 7816 based verification algorithms. This is under development in ISO/IEC JTC 1's Subcommittee 37 Working Group 5.
- ▷ This revision of this document still uses the term MATCH-ON-CARD instead of the term ON-CARD COMPARISON which has been adopted by the Working Group 11 of ISO/IEC SC 17, and Working Group 5 of ISO/IEC SC 37. The older term, MATCH-ON-CARD, is deprecated in those forums.
- ▷ Thoughout this report the submitted implementations are identified as MX2*x*, with $x \in \{A T\}$. This association was instantiated to support automated administration of the test and to effect a containment of the participant identities within specific personnel at NIST. The letter codes were assigned in approximate order of receipt of the implementation and its passing of subsequent validation and conformance trials. The use of these letters is maintained in this report to conserve space in its many tables. For reference, the letters are associated with the providers' names in a running footnote.
- \triangleright Letters MX2A \rightarrow MX2M denote implementations tested in the period 2007 to 2008. Letters MX2N \rightarrow MX2T refer to those tested from late 2008 to 2009. See Table 3.
- ▷ A glossary of terms and definitions is given on page 5.
- ▷ Much of the tabulated content in this report was produced automatically. This involved the use of scripting tools to generate directly typesettable LATEX content. This improves timeliness, flexibility, maintainability, and reduces transcription errors.
- ▷ This PDF file is likely to be better viewed in print than on-screen.
- ▷ Readers are asked to direct any correspondence regarding this report to the MINEXII@NIST.GOV.

Acknowledgements

The authors would like to thank the Department of Homeland Security's Science and Technology Directorate as sponsors of this work.

The authors would like to take this opportunity to again thank those individuals and organizations identified in the MINEX II evaluation plan [9] for the contributions toward the initiation of this work.

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

Terms and Definitions

Table 1 gives MINEX-specific definitions to various words and acronyms found in this report.

No.	Term	Definition
1	MOC	Match-on-Card
2	SMOC	Secure Match-on-Card
3	ANSI	American National Standards Institute
4	ISO	International Organization for Standardization
5	IEC	International Electrotechnical Commission
6	SC 17	Subcommittee responsible for development of indentfication card standards
7	SC 37	Subcommittee responsible for development of biometrics standards
8	M1	The standards body that formulates comments toward SC 37 biometrics standards
9	INCITS	International Committee for Information Technology Standards
10	INCITS 378:2004	U.S. standard governing the templates
11	ISO/IEC 19795-2:2005	International variant of the INCITS 378 format
12	Compact card	Three-bytes per minutia format defined in ISO/IEC 19794-2:2005
13	Standard template	Record containing standard $(x, y, \theta, type, quality)$ minutiae
14	Proprietary template	Template comparable only with a template from the same vendor
15	Enrollment template	Synonym for reference template
16	Reference template	Template from the first sample of a subject, stored on card
17	Authentication template	Template generated from a second sample of a subject, or from an impostor's sample
18	Matcher	Software function that compares two templates to produce a similarity score
19	Generator	Software function that accepts an image and produces a template
20	Native matching	Comparison by matcher from vendor X of two templates from vendor X's generator
21	BIT	Biometric Information Template (See ISO/IEC 7816)
22	BDB	Biometric Data Block (See SC37's Harmonized Vocabulary[1])
23	Genuine	Comparison of templates from the same person
24	Impostor	Comparison of templates from different individuals
25	Verification	One-to-one comparison
26	Authentication	Synonym for verification
27	FAR	False accept rate (i.e. transactional outcome)
28	FRR	False reject rate (i.e. transactional outcome)
29	FMR	False match rate (i.e. 1:1 single sample comparison outcome)
30	FNMR	False non-match rate (i.e. 1:1 single sample comparison outcome)
31	DET	Detection Error Tradeoff characteristic
32	SDK	Software Development Kit
33	APDU	Application Protocol Data Unit
34	API	Application Programming Interface
35	DHS	U. S. Department of Homeland Security
36	NIST	National Institute of Standards and Technology
37	POE	Referring to samples collected in a port of entry
38	BVA	Referring to samples collected and port of a biometric visa application
39	MINEX	The Minutiae Interoperability Exchange program
57		The filling metoperability Exchange program

Table 1: Glossary of MINEX II related terms

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

1 Introduction

The approval of the U.S. and international fingerprint minutia template standards, specifically INCITS 378 and ISO/IEC 19794-2:2005, have created the possibility to establish an interoperable multivendor marketplace for applications involving fast, economic, and accurate interchange and matching of compact biometric templates.

The standards are not application specific. They define formats which can be used for both MATCH-OFF-CARD and MATCH-ON-CARD. While the viability of the templates for MATCH-OFF-CARD has been assessed previously [8, 7, 6], the MATCH-ON-CARD application, which is almost always conceived of as occuring on conformant ISO/IEC 7816 smart cards, has not been independently and publicly tested.

Thus, the MINEX II trial was designed to answer three important and outstanding questions surrounding MATCH-ON-CARD, namely:

- ▷ What is the accuracy loss incurred using the three bytes per minutia ISO/IEC 19794-2 COMPACT CARD format favored for MATCH-ON-CARD, vs. the six bytes per minutia INCITS 378 format?
- ▷ What loss in accuracy is incurred when compact fingerprint minutia templates are matched on ISO/IEC 7816 cards vs. on a resource-rich processor?
- ▷ What is the time needed to execute the algorithmic matching operation?

The first question was addressed in the MINEX II Evaluation Plan [9]. While the last question can be estimated by ad hoc usage, it is the near-term imperative to answer the second question that served as the primary motivator for the MINEX II study.

The results of MINEX II may have implications for projects such as the US Government's Personal Identity Verification (PIV) program² and the U.S. Department of Homeland Security's Transportation Worker Identification Credential (TWIC). PIV was initiated by Homeland Security Presidential Directive 12³. This mandated the establishment of a common identification standard for federal employees and contractors. It required interoperable identity credentials for physical and logical access to federal government facilities and systems. In response, NIST released FIPS 201⁴ in February 2005, which includes the definition of an identity credential. It specified the inclusion of data from two fingerprints as a third authentication factor. The format for this information was finalized in February 2006, when NIST *Special Publication 800-76* specified the MINEX II profile of the INCITS 378 standard. A broad timeline is given in Table 2.

1.1 MINEX background

The wider MINEX program is intended to improve template-based interoperability from the imperfect state reported in MINEX 04 and MTIT[7] toward that achievable with image-based implementations. The approach is to conduct several programs, MINEX II, III, IV etc, each of which will embed development, evaluation, targeted feedback and consultation activities between NIST, industry and other interested parties. Within scope are any issues to do with fingerprint minutiae as an interoperable biometric. Typical outcomes will be measurements of accuracy, processing time, template size, and commentary on the relevant standards, studies of utility of quality measures, calibration information, and new metrics. Two prior tests have been conducted:

MINEX 04 was conducted as an initial comparison of image vs. minutia-based interoperability. It assessed the core algorithmic ability of fingerprint matcher Z to compare minutiae templates from template generators X and Y. It compared the matching accuracy in that case with fully proprietary templates on the same sets of archival images. The test adopted the INCITS 378 template as a base standard. The test is now closed. http://fingeprint.nist.gov/minex04

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

²See http://csrc.nist.gov/piv-program/

³The text of HSPD 12 is here: http://www.whitehouse.gov/news/releases/2004/08/20040827-8.html

⁴See Federal Information Processing Standards Publication 201, Personal Identity Verification for Federal Employees and Contractors and related documents here: http://csrc.nist.gov/piv-program

No.	Period	Event
1	August 25 1986	Minutiae standardization begins: ANSI/NBS ⁶ -ICST 1-1986 Data Format for Fin-
1	August 25 1700	gerprint Information Interchange standard.
2	December 12 2003	Initial discussions for MINEX 04 at NIST
3	March 8 2004	INCITS 378 Finalized
4	August 27 2004	Homeland Security Presidential Directive 12 is signed
	0	
5	September 21 2004	MINEX 04 is announced publicly
6	February 25 2005	Publication of FEDERAL INFORMATION PROCESSING STANDARD-201
7	September 15 2005	Publication of ISO/IEC 19794-2 Biometric Data Interchange Format - Finger
		minutiae data
8	December 2005	Amendments to INCITS 378 discussed in Toronto meeting of M1
9	February 1 2006	NIST Special Publication 800-76-1 is released
10	March 6 2006	MINEX 04, NISTIR 7296, is released
11	March 6 2006	ONGOING MINEX is announced
12	March 12 2007	MINEX II Concept document released for comment
13	August 15 2007	MINEX II Test Plan finalized
14	October 14 2007	MINEX II Phase I results returned to suppliers
15	November 15 2007	MINEX II Phase II submission deadline
16	January 16 2008	MINEX II Phase II report is submitted for release
17	June 20 2008	NIST announces the Phase III round of testing
18	March 24 2008	NIST comments toward revision of ISO/IEC 19794-2
19	October 30 2008	MINEX II Phase III submission deadline
20	February 27 2009	Latest CD text of revised ISO/IEC 19794-2
21	March 30 2009	NIST comments toward revision of ISO/IEC 19794-2:2005
22	April 27 2009	MINEX II Phase III report is submitted for release

Table 2: MINEX chronology and related events.

Ongoing MINEX is a continuing program of interoperability assessment intended to measure conformance and interoperability of INCITS 378:2004 samples. The test uses one expanded partition of the MINEX 04 data to formulate interoperable groups of matchers and template generators. One client of Ongoing MINEX is the US Government's PIV program which has its own set of criteria against which the interoperable group is formed. The test results are available to other applications or programs which may elect to set their own criteria for interoperable performance. The test remains open⁵

1.2 MINEX II objectives

The MINEX 04 evaluation was intended to assess the viability of the INCITS 378 templates as the interchange medium for fingerprint data. The main objective was to determine whether standardized minutia reference templates can be subsequently matched against an authentication template from another vendor. MINEX II retains this objective but focuses the activity to matchers using ISO/IEC 19794-2 COMPACT CARD templates on ISO/IEC 7816 cards.

MINEX II is intended to measure the core algorithmic capabilities of fingerprint matching algorithms running on standardized ISO/IEC 7816 smart cards. Specifically the MINEX II program has

- ▷ instantiated a mechanism for MATCH-ON-CARD testing,
- ▷ measured the accuracy of MATCH-ON-CARD implementations using ISO/IEC 19794-2:2005 compact card minutia templates,
- ▷ timed the various operations, and
- ▷ demonstrated the viability of INCITS 378:2004 as a parent to the ISO/IEC 19794-2 compact card. This leveraged transcoding code residing in NIST's open-source BIOMDI (Biometric Data Interchange) repository⁷.

⁷See http://biometrics.nist.gov/nigos

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

⁵For results and participation see http://fingerprint.nist.gov/minex.

Card	Fingerprint Matcher	Vendor		NIST	Phases I, I	I, and III		
Vendor	Vendor	IDs		IDs	Generator	Matcher		
TecSec	Precise Biometrics	00990100	000B0100	MX2A		Ι		
TecSec	Precise Biometrics	00990101	000B0101	MX2B		Ι		
Internet Risk Management	Neurotechnologija	00312001	00312001	MX2C	I	Ι		
Sagem Morpho	Sagem Morpho	001D6221	001D0002	MX2D	I, II	I, II		
Sagem Morpho	Sagem Morpho	001D6221	001D0003	MX2E	I, II	I, II		
Oberthur	ID 3	0415010B	003F0301	MX2F		I, II		
Oberthur	ID 3	0415010C	003F0108	MX2G		I, II		
Oberthur	ID 3	0415010C	003F0109	MX2H		I, II		
Oberthur	ID 3	0415010C	003F0216	MX2I		I, II		
Oberthur	ID 3	0415010C	003F0222	MX2J		I, II		
Oberthur	ID 3	0415010C	003F0228	MX2K		I, II		
Giesecke & Devrient	Giesecke & Devrient	41570001	41570010	MX2M		П		
Gemalto	Innovatrics	41580002	00350095	MX2N	III	III		
Gemalto	Innovatrics	41580002	00350096	MX2O	III	III		
Oberthur	ID 3	1433C6FC10010D	003F0310	MX2P		III		
Oberthur	ID 3	1433C6FC10010D	003F0320	MX2Q		III		
Gemalto	Micro-Packs	41580001	41610010	MX2R		III		
Gemalto	Micro-Packs	41580001	41610011	MX2S		III		
Gemalto	Cogent	41580001	00173143	MX2T	III	III		

Table 3: Teams entering MINEX II Phases I and II.

Only results from Phases II and III are published. The last two columns indicate the components the teams elected to enter into the various phases. The template generator was optional, the matcher was mandatory. Empty cells indicate the provider elected not to participate, or failed to submit according to the deadline. Participation in Phase I or II (2007-2008) was not a pre-requiste of Phase III (2008-2009). (which is indicated in blue).

The following are specifically not within the current scope of this evaluation.

- ▷ The ISO/IEC 19794-2 "record" and "card normal" templates.
- ▷ Ridge count, core and delta, and zonal quality extensions.
- ▷ Proprietary templates, and non-standard extensions to any standardized minutia format.
- ▷ Evaluation of readers, including performance, conformance and interoperability.
- ▷ Evaluation of ruggedness or durability of the card.
- ▷ On-card template generation (i.e. extraction of minutiae from images).
- ▷ Template update or adaptation.
- ▷ A formal test of conformance to parts of ISO/IEC 7816. However, the test uses ISO/IEC 7816 parts 4 and 11, and conformance to the relevant clauses thereof was required.
- ▷ Devices not conforming to ISO/IEC 7816, including all system-on-card and sense-on-card devices embedding proprietary templates⁸.

1.3 Participation

With the primary MINEX II objective to ascertain MATCH-ON-CARD capability by measuring fingerprint algorithm accuracy in the intended environment (i.e. the card), the test allowed card vendors to team with several fingerprint algorithm vendors, and vice versa. This policy reflected the notion that if accuracy can be traded against speed, then a fingerprint supplier's technology may demonstrate improved accuracy when implemented on a more capable card. NIST therefore required identification of both the card and fingerprint technology suppliers, and these are presented in Table 3. Note

MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

⁸These devices should only be tested in a live scenario test, with device instrumentation to capture proprietary templates for offline cross-comparison.

Fingerprint	NIST	IBIA
Vendor	ID	ID
Cogent	Α	00170A47
Dermalog	В	000D088E
Bioscrypt	С	00020004
Sagem Morpho	D	001D0100
Neurotechnologija	Е	00310100
Innovatrics	F	00350A01
NEC	G	00118201
Cross Match Technologies	N	00180406
L1/Identix	1C	000C0D60
Precise Biometrics	1D	000B0100
XTec	1F	00340035
SecuGen	1G	000A0035
BIO-key International	1J	00300258
Motorola	1L	002E0101
Aware	1M	003B0101
Sonda Technologies	1N	003C0101
Neurotechnologija	1T	00310101
Aware	1Y	003B0102
ImageWare	2A	00430011

Table 4: Suppliers	of Ongoing MI	NEX compliant terr	plate generators
The second se	0 - 0		1 0

- ▷ The teams participating in MINEX II are identified by their full name in Table 3, and by a letter code and an abbreviated name in the running footer of each page.
- ▷ The test was conducted in three phases. The first was intended as a preliminary small scale test with release of results only to the provider. Per the participation agreement[9], Table 3 indicates the names of the teams in both phases. One team elected to participate only in Phase II. Two others withdrew after Phase I. The one team that participated in all three phases was joined in Phase III by three new teams.
- Participants were encouraged, but not required, to supply an INCITS 378 fingerprint minutia template generator. One elected to do so in Phases I and II, and a further two did so in Phase III.
- ▷ In addition INCITS 378 templates from the suppliers listed in Table 4 were used. Most of these suppliers did not take part in the MINEX II evaluation but their templates are archived in support of the ONGOING MINEX program⁹.

1.4 Relationship to NIST's SBMOC activity

A concurrent and related but procedurally separate activity, SECURE BIOMETRIC MATCH-ON-CARD (SBMOC) FEASIBIL-ITY STUDY was conducted at NIST¹⁰ as a demonstration of MATCH-ON-CARD authentication in which the communications channel was secured, the privacy and integrity of the biometric data was cryptographically protected and the card was authenticated to the reader. This was done using a contactless interface. The operations were timed, with the goal of conducting an authentication within 2.5 seconds. The results have been published as NISTIR 7452 *Secure Biometric Match-on-Card Feasibility Report* [5].

Not all participants in the SBMOC entered MINEX II , and vice versa.

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

⁹See http://fingerprint.nist.gov/minex

¹⁰MINEX II was run by the Information Access Division. The SBMOC activity was conducted by the Computer Security Division.

2 Test implementation

2.1 Concept

The MINEX II evaluation measures MATCH-ON-CARD performance at low false match rates with statistical robustness. This necessitates the execution of very large numbers of genuine and impostor comparisons. These cannot be conducted on physical cards for reasons of total time and card durability. Thus, the fundamental approach to testing is to run a PC-based implementation of the card algorithm, and then to verify that the PC algorithm is the same as that on the card by re-running a subset of the template comparisons on the actual card, and checking that the output similarity scores are identical.

2.2 Procedures

The test was implemented by requiring participants to submit the minutiae matching algorithm as an SDK conforming to the MINEX II API specification and a card supporting the MINEX II APDUS. Both APIs are documented in the accompanying MINEX II Evaluation Plan [9].

NIST authored and released open-source software (see section 3.6) for conversion of INCITS 378 to ISO/IEC 19794-2 COMPACT CARD templates. This operation respected the ISO/IEC 7816-11:2004 Biometric Information Template (BIT) parameters for minutia count, and sort order. This process is described in detail in the evaluation plan [9].

Execution of the test can be summarized as a six stage process:

- 1. Validation of SDK functionality This procedure has been document previously [8];
- 2. Validation of MOC functionality The MATCH-ON-CARD procedure is to execute all necessary APDUs and check for errors (see section 6);
- 3. Use of (optional) SDK template generators to produce INCITS 378 templates, and retrieval of baseline ONGOING MINEX templates from archival storage;
- 4. Reading and storage of ISO/IEC 7816-11:2004 BIT card capability records from the submitted cards. The salient BIT properties are recorded in Table 13;
- 5. Execution of MATCH-OFF-CARD (i.e. using the SDK). This process embeds on-the-fly conversion of INCITS 378 to ISO/IEC 19794-2 COMPACT CARD templates while respecting the BIT. The number of template comparisons was 2747804 for each matcher tested¹¹
- 6. Repetition of 40000 template comparisons on the card, timing thereof, and crosscheck of matcher scores against the SDK output.

2.3 Fingerprint datasets

A single corpus of fingerprint images was used for MINEX II testing. This is referred to as the POEBVA data set, and it is identical to that described in the MINEX 04 report [8] except that more samples have been drawn from the same population. The dataset is distinguished from many biometric testing corpora in two valuable ways:

▷ First, the enrollment and authentication images are collected at separate locations in different environments with different sensors. The BVA images are collected as part of a non-immigrant visa application process. The POE images are collected later when the subject crosses the U.S. border at a Port of Entry.

MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

¹¹This test is repeated for each combination of template generators.

On Card	Off Card
 ▷ Reference template generator is selected by manufacturer of issuance system, A. Format is ISO/IEC 19794-2. ▷ Matcher is selected by provider of card stock, B. It compares ISO/IEC 19794-2 instances. ▷ Verification generator from reader maufacturer, C. It would extract INCITS 378 data, and convert to ISO/IEC 19794-2. ▷ Often A ≠ B ≠ C; sometimes A = B 	 ▷ Reference template generator is selected by manufacturer of issuance system, A. Format is INCITS 378 or ISO/IEC 19794-2. ▷ Matcher selected by reader manufacturer, B. It compares either INCITS 378 or ISO/IEC 19794-2 records. ▷ Verification template generator selected by reader manufacturer, C. It prepares a INCITS 378 instance, possibly supplemented with proprietary features. ▷ Often A ≠ B, B = C

Table 5: Typical relationships and roles in interoperable applications.

▷ Second, the POE authentication images were collected without human intervention in an autocapture process. This embeds an automated quality-in-the-loop assessment to select the best image, ahead of a timeout. This has the effect of elevating overall quality.

Together these aspects enhance the operational relevance of the MINEX II results.

2.4 Interoperabilty

The MINEX II study addressed the conventional logical or physical access paradigm in which a user's smart card, populated with a reference template provided by vendor A and a matching algorithm from vendor B, is used in an authentication attempt in which a template is generated from an acquired image by the generator from a third vendor, C. This tripartite scenario was examined in MINEX 04 and error rates were generally degraded relative to the case where the verification template generator and matcher were provided by the same supplier, as they may well be in off-card matching. Table 5 summarizes typical bipartite and tripartite relationships in federated interoperable applications.

3 Metrics

3.1 Performance measures

This document quantifies accuracy and interoperability in terms of false non-match and false match error rates, FNMR and FMR. The quantities are computed empirically. If s denotes a matcher score obtained by comparing two samples from the same person, and N(t) is the number of such scores below threshold, t,

$$N(t) = |\{s < t\} \cap \mathcal{G}|, s \in \mathcal{G}$$

$$\tag{1}$$

where G denotes the set of all genuine comparison scores. FNMR is then the fraction of genuine comparisons for which the score is less than the operating threshold:

$$FNMR(t) = \frac{N(t)}{N(\infty)}$$
(2)

where $N(-\infty)$ is the number of genuine comparisons conducted. Likewise, when *s* denotes a score obtained by comparing samples from different persons persons, and M(t) is the number of such scores greater than or equal to a threshold, *t*,

$$M(t) = |\{s \ge t\} \cap \mathcal{I} |, s \in \mathcal{I}$$
(3)

MX2D = Sagem Morpho	MX2E = Sagem Morpho	MX2G = Oberthur / id3	MX2H = Oberthur / id3
MX2I = Oberthur / id3	MX2J = Oberthur / id3	MX2K = Oberthur / id3	MX2M = Giesecke - Devrient
MX2N = Gemalto / Innovatrix	MX2O = Gemalto / Innovatrix	MX2P = Oberthur / id3	MX2Q = Oberthur / id3
MX2R = Gemalto / Micro Packs	MX2S = Gemalto / Micro Packs	MX2T = Gemalto / Cogent	

	Number o	f unique scor	re values
	Genuine	Impostor	All
MX2D	19030	7341	19993
MX2E	19558	7443	19993
MX2G	101	24	101
MX2H	110	22	110
MX2I	103	20	103
MX2J	103	20	103
MX2K	103	21	103
MX2M	49	14	49
MX2N	52100	11540	53689
MX2O	51178	11625	53547
MX2P	18887	2896	19125
MX2Q	18846	2968	19132
MX2R	16417	1457	16421
MX2S	16485	1531	16491
MX2T	2935	682	2949

Table 6: Number of unique similarity scores. Note that the implementations provided in Phase III, i.e. MX2N onwards, produce larger numbers of scores. This follows the Phase II conclusion that fewer scores inhibit fine control of FMR.

where \mathcal{I} denotes the set of all impostor scores. FMR is then the fraction of impostor comparisons resulting in a score greater than or equal to the operating threshold:

$$FMR(t) = \frac{M(t)}{M(-\infty)}$$
(4)

where $M(\infty)$ is the number of impostor comparisons conducted.

FMR is regarded as a measure of security, i.e. the fraction of illegitmate matching attempts that result in success.

These error rates must be understood as being *matching* error rates, not *transactional* rates. The ISO/IEC SC 37 Working Group 5 has established different terms for these rates: FMR and FNMR refer to comparisons of single samples, while FAR and FRR apply to the outcome of a human-system transaction in which a user might, for example, make multiple attempts and multiple finger placements.

3.2 Thresholds in the DET computation

As is typical in offline testing [2], this report does not fix an operating threshold but instead uses all the scores from a matcher as thresholds that could be used in actual operation.

This testing practice contrasts with fielded MATCH-ON-CARD applications in which the card is configured with a fixed operating threshold, against which a *decision* is rendered.

For MINEX II we required the SDK and the card to produce integer matcher scores on at most [0, 65535]. The advantage over just producing true-false decisions is that it allows a survey over *all* operating points, *t*, and the production of a DET characteristic. This is a plot of FNMR(*t*) against FMR(*t*)¹² and, as the primary output of a biometric performance test, is vital in establishing the tradeoff between the inconvenience associated with incorrect rejection of legitimate users, and the incorrect acceptance of fraudulent users.

3.3 Thresholds for computation of interoperability matrices

Setting an operational threshold is often a sensitive issue because of implications for security, convenience, throughput, and cost. It is always application specific. Although this report makes no recommendations on threshold setting, it has

MX2D = Sagem Morpho
MX2I = Oberthur / id3
MX2N = Gemalto / Innovatrix
MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

¹²DET characteristics sometimes plot Normal deviates, i.e. a plot in which the FNMR and FMR are (nonlinearly) transformed by the inverse CDF of N(0, 1). This is abandoned here because the score densities are not Normal.

necessarily adopted "default" performance figures of merit in support of comparison objectives. Unless stated otherwise, the results in this report correspond to the threshold that produces a FMR of 0.01. The figure of merit is the FNMR at that point. The value 0.01 should not be construed as a recommended operating point but as a value at which error rate differences may be readily observed.

The interoperability matrices show FNMR for fixed FMR values, e.g. f = 0.01. However, this requires the computation of FNMR(t_0) for $t_0 = \text{FMR}^{-1}(f)$, and while this is trivial for continuous matcher scores it is not so for tied integer scores. The inverse FMR computation is approximate because there is no value for which $\text{FMR}(t_0)$ is exactly f. So the threshold actually used, t, is the lowest observed score value for which $\text{FMR}(t) \le f$. In some cases this yields FMR values substantially below the target f. This is a conservative policy decision in the sense that FMR is on the "safe" side of f.

This issue is especially apparent in MATCH-ON-CARD implementations because, as Table 6 shows, some algorithms emit only a limited number of unique scores, perhaps as a result of a need to conserve computational resources. The values are observations over $O(10^7)$ comparisons. In principle, each value can be used as a threshold against which acceptance and rejection decisions are based. The lack of possible impostor values precludes a fine grained setting of security policy. The MINEX 04 matchers exhibited many more unique values. The fused scores used in Table 8 take on more unique values because of the eq.(6) sum.

This issue is not critical for DETs, which plot the error rates at all possible thresholds with straight lines connecting them. Note, that theory indicates [13] that points on the convex hull of the DET curve between two operating thresholds are accessible by randomly using one or the other for each comparison. The operational use of this practice is not known.

3.4 Handling failure to enroll

The MINEX test protocols have all required template generators to produce a standard template whatever the input image. Thus if a template generator was presented with an image of such poor quality that it would operationally reject it (i.e. a failure to enroll), the output in MINEX II is nevertheless required to be a template that is a valid input to the matcher. The template is allowed to contain zero minutiae. Such templates are formally conformant to INCITS 378.

When a SDK-based or MOC-based algorithm is presented with a zero minutiae template it will produce a low similarity score (e.g. zero). The effect of this in an impostor comparison is a correct rejection and improved FMR. For a genuine transaction, the result is a false non-match and degraded FNMR.

3.5 **Open-source support for MOC**

MINEX II demonstrated an unprecedented level of openness in its evaluation methods. Specifically the test plan was developed in conjunction with industry and both the template conversion and MATCH-ON-CARD test harness were fully open during their development phase, as decribed below.

3.6 Support for biometric data interchange standards

The BIOMDI open source project¹³ contains several software library and program packages for handling records specified in INCITS and ISO biometric data format standards. The MINEX II test program uses the finger minutia package to process the INCITS 378 records, converting them to ISO compact card format. In addition, several tools in this package are used to validate the records, or simply to view them.

3.7 Support for MATCH-ON-CARD implementations

The BIOMAPP open source project¹⁴ contains the source code for the match on card test drivers, the tag-length-value (TLV) object processing, and an example SDK test driver. The programs within the BIOMAPP project make use of the

Μ

Μ

¹⁴Ibid.

1X2D = Sagem Morpho	
1X2I = Oberthur / id3	
1X2N = Gemalto / Innovatrix	
IX2R = Gemalto / Micro Packs	

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

¹³See http://biometrics.nist.gov/nigos

finger minutiae libraries from the BIOMDI project. Also, the card test driver utilizes the pcsclite library described in Appendix A.

The goal of the BIOMAPP match on card package is to achieve independence from any particular vendor's middleware. The software communicates directly with the card at the APDU level, removing any need for a middleware API or custom smart card software.

4 MOC Accuracy

4.1 Uncertainty estimates

This section includes estimates of various false non-match rate (FNMR) and false match rates (FMR). These were estimated over fixed numbers of template comparisons.

- For single finger matching, the number of genuine and impostor comparisons was 247924 and 2499880 respectively corresponding to the use of two impressions of each of the left and right index fingers of 123962 unique subjects. The left index finger from each subject was compared with up to ten other left index fingers. The right index finger was compared with the right index finger of the same individuals. Each finger of each subject was used in only one genuine comparison.
- ▷ For two-finger matching, the number of genuine and impostor comparisons was 123962 and 1249940. Again subjects were reused up to ten times.

The error rates follow binomial statistics, such that if experiments of the same size were repeated using samples drawn from the same population then, with 95% coverage, the error rate measurement would fall between $p - u \le p \le p + u$ where p is the true error rate,

$$u = \Phi^{-1}(1 - \alpha/2)(p(1 - p)/N)^{\frac{1}{2}}$$
(5)

and $\alpha = 0.05$. This Normal approximation to the binomial distribution leads to the following estimates of uncertainty.

- ▷ for FMR = p = 0.0001, N = 1249940, u = 0.00002,
- ▷ for FMR = p = 0.01, N = 1249940, u = 0.0002, and
- ▷ for FNMR = p = 0.01, N = 123962, u = 0.0006.
- ▷ for FNMR = p = 0.1, N = 123962, u = 0.0017.

These estimates apply to the population of fingerprints identified in 2.3 and do not represent systematic effects associated with the caveats identified on page 3.

4.2 Match-on-Card vs. Match-off-Card

Three vendors have elected to submit matching algorithms to NIST's on-card MINEX II *and* off-card MINEX 04 trials. Table 7 shows the accuracy for those providers' implementations: While many of the differences are small and not, in isolation, statistically significant, the MATCH-OFF-CARD error rates are *all* lower than the MATCH-ON-CARD rates. The last row of the Tables shows the ratio of the total false non-matches if all the generators were used in equal proportion. The result is that overall MATCH-ON-CARD algorithms produce from about 20% to 80% more false non-matches than the providers' MATCH-OFF-CARD implementations ¹⁵. This effect is larger at lower FMR values. Note intra-vendor differences in accuracy are usually less than the inter-vendor differences reported in Table 8. These observations apply to standard templates only.

 MX2D = Sagem Morpho
 MX2E = Sagem Morpho

 MX2I = Oberthur / id3
 MX2J = Oberthur / id3

 MX2N = Gemalto / Innovatrix
 MX2O = Gemalto / Innovatrix

 MX2R = Gemalto / Micro Packs
 MX2S = Gemalto / Micro Packs

MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

¹⁵Note that ratio measurements have larger undertainties associated with them.

	100	MX2D	0.0116	0.0061	0.0041	0.0111	0.0000	0.0080	0.0142	0.0086	0.0154	0.0140	0.0087	0.0075	0.0067	0.0114	0.0068	0.0062															
	FMR = 0.0001	D	0.0068 0.	0.0048 0.		0.0084 0.	0.0060 0.0	0.0063 0.	0.0123 0.			0.0121 0.	0.0056 0.	0.0054 0.	0.0056 0.	0.0072 0.	0.0047 0.	0.0050 0.	1.35														
(2D	FMR = 0.001	MX2D	0.0068	0.0036	0.0026		0.0054	0.0046	0.0084		-	0.0087	0.0056	0.0044	0.0039	0.0067	0.0042	0.0039	1.31														
(b) D vs. MX2D				0.0029		0.0054	0.0042		0.0075	0.0037		0.0069		0.0030	0.0033		0.0031	0.0032	1.		01	MX2N	0.0373	0.0241	0.0226	0.0201	0.0246	0.0275	0.0364	0.0117	0.0365	0.0399	0.0759
	FMR = 0.01	_		17 0.0020	12 0.0015	30 0.0040	25 0.0030	23 0.0025	15 0.0049			12 0.0046	25 0.0032	17 0.0023	20 0.0022		18 0.0022	0.0020	1.23		FMR = 0.0001	F M)	0.0292 0.0				0.0114 0.0	0.0304 0.0	0.0287 0.0	0.0128 0.0	0.0348 0.0	0.0325 0.0	0.0145 0.0
-	FN		0.0022	0.0017	0.0012	0.0030	0.0025	0.0023	0.0045	0.0022		0.0042	0.0025	0.0017	A 0.0020	V 0.0027	0.0018	(0.0019	Ratio	7	.001	MX2N	0.0225 0			_	0.0162 0	0.0168 0	0.0237 0	0.0075 0	0.0245 0		0 0177 0
[A	B		ш	щ	U	Z	1		1F	1]	1L	1M	1N	1T	1Y	Râ	(c) F vs. MX2N	FMR = 0.001	ц	0.0166	0.0151	0.0096	0.0117	0.0067	0.0169	0.0168	0.0069	0.0191	0.0166	0.0077
	FMR = 0.0001		0.0059	0.0208	0.0114	0.0144	0.0424	0.0260	0.0311			0.0292	0.0549	0.0144	0.0250	0.0338	0.0175	0.0211	1.16	(c)	0.01	MX2N	0.0127	0.0098	0.0092	0.0078	0.0102	0.0099	0.0146	0.0044	0.0154	0.0166	0 0114
-		T A	0 0.0063	1 0.0174			7 0.0360	4 0.0260	6 0.0311			3 0.0197	1 0.0312	0 0.0124	0 0.0268	4 0.0269	3 0.0213	2 0.0203			FMR = 0.01	ц	0.0078	0.0069	0.0047	0.0056	0.0033	0.0082	0.0086	0.0034	0.0097	0.0088	0 0041
vs. MX2T	FMR = 0.001			7 0.0111			3 0.0227	6 0.0144	9 0.0176			2 0.0173	4 0.0321	6 0.0070	3 0.0130	1 0.0194	0 0.0083	4 0.0102	1.78				А	В	D	н	н	IJ	z	1C	1D	1F	11
(a) A vs.			4 0.0022	53 0.0047		34 0.0058	26 0.0103	69 0.0086	94 0.0119	36 0.0054		96 0.0082	88 0.0154	34 0.0036	52 0.0083	4 0.0111	36 0.0070	l9 0.0074															
	FMR = 0.01			27 0.0053		26 0.0034	54 0.0126		52 0.0094			43 0.0096		18 0.0034	40 0.0062	51 0.0114	29 0.0036	35 0.0049	1.85														
	FN		0.0011	0.0027	0.0022	0.0026	0.0054	0.0042	0.0062	0.0028	0.0093	0.0043	0.0085	0.0018	0.0040	0.0061	0.0029	0.0035	Ratio														

Table 7: Comparison of MATCH-OFF-CARD (c. 2004) and MATCH-ON-CARD (c. 2007-2008) matchers from three providers, Sagem-Morph (D), Cogent (A) and Innovatrics (F). The values are two-finger sum-fused FNMR values for three FMR operating points. Cells are colored green when the PIV FNMR ≤ 0.01 criterion is met. The PIV criterion for FMR is also FMR ≤ 0.01 ; success at lower FMR values is surplus to the requirement. The enrolment template generators are identified in the rows. The verification template generator and the matcher is identified in the column header.

0.01840.0138 0.0241

0.01670.0167

0.0120 0.0088 0.01560.0143

0.0203

0.00950.00830.00670.0107

0.00840.00740.0088.73

0.00950.0052

0.00550.00430.0033 0.0048

1M1N 11

0.0122 0.0184

0.0222.17

0.0143.40

0.0102

1Y Ratio

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs

MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

NIST has not measured accuracy of MATCH-OFF-CARD implementations from these providers since they were submitted to MINEX 04 in 2004.

Note that Sagem-Morpho had submitted the matcher with NIST designation 1E to ONGOING MINEX in 2006 under the name "Morpho Match-on-Card, Software Version 1.0". It attained the PIV accuracy specification¹⁶. Its FNMR performance differs from the MX2D implementation tested here by only ± 0.0003 . Differences may be attributed to

- ▷ the use ISO/IEC 19794-2 COMPACT CARD templates here vs. INCITS 378 templates in ONGOING MINEX , and
- ▷ the larger number of impostor comparisons here (1249940) vs. ONGOING MINEX (124994).

Thus, we conclude that the 2006 implementation submitted for PIV evaluation was indeed the MATCH-ON-CARD algorithm submitted here.

4.3 Comparison of MOC implementations

Figure 1 shows the Detection Error Tradeoff characteristics for the MATCH-ON-CARD implementations tested. The top and bottom plots show, respectively, the result for single finger, and sum-fused two-finger, verification. We make the following observations.

- ▷ There is a large variation in accuracy between MATCH-ON-CARD matchers. In the operationally interesting range $0.0001 \le \text{FMR} \le 0.01$, the rows of Table 8 show that the most accurate implementations give FNMR values an order of magnitude better than the least accurate.
- ▷ In the operationally interesting range $0.0001 \le FMR \le 0.01$ the curves tend not to cross. Thus, if one matcher is more accurate at one threshold, it will also be more accurate elsewhere. This means that *comparative* evaluation of MATCH-ON-CARD implementations at one threshold is substanially representative of another. This result is not generally true however.
- \triangleright False non-match rates at FMR = 0.0001 are between two and four times worse than those at FMR = 0.01.
- ▷ The two-finger false non-match rates are almost an order of magnitude lower than the single-finger rates.
- Accuracy is generally improved when both templates are produced by the same generator ¹⁷. The exceptions are for MX2D and MX2E which exhibit better performance when used with the MX2D generator; and likewise MX2T when paired with the A generator. These two effects are evident in the data reported in the MINEX 04 trial: Matchers give greater accuracy on templates from the same source and to a lesser extent when one of the templates is produced by the matcher provider's template generator.


4.4 Would accuracy be sufficient for PIV compliance?

The question of whether a MATCH-ON-CARD matcher would qualify for the U.S. Government's Personal Identity Verification program is addressed here by subjecting the MATCH-ON-CARD implementation to the NIST Special Publication 800-76-1 interoperable accuracy specification. This states that a matcher submitted for PIV shall be capable of verifying INCITS 378 templates from all previously qualified template generators. This measurement activity is conducted by NIST under the ONGOING MINEX name. The process requires the supplier of the matcher to also submit a template generator. This requirement derives from the MATCH-OFF-CARD situation in which the reader is equipped with a sensor, template generator and matcher. However, because NIST acceeded to requests from the industry to allow submission of a MATCH-ON-CARD algorithm without an accompanying template generator, we are only able to conduct the following *simulation* of the PIV assessment process.

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

¹⁶The results are posted at http://fingerprint.nist.gov/minex/Results.html

¹⁷This result, for generator B, appeared in the first edition of this report - see http://fingerprint.nist.gov/minexII/minex_report1.pdf.



(b) Two fingers (sum-rule fusion)

Figure 1: DET characteristics.

The FNMR vs. FMR tradeoffs are shown for two pairs of reference and authentication generators: (F, MX2D) as dashed lines, and (A, MX2D) as solid

- 1	mes.

We use the current list of ONGOING MINEX qualified template generators to prepare reference templates (notionally for storage on a card), which we then verify against templates from the one MINEX II submitted generator, MX2D, using the MATCH-ON-CARD algorithm under test. This mimics the case in which the supplier of the card were to license and submit Sagem Morpho's template generator to a formal ONGOING MINEX compliance test. The MX2D generator is used because it emits minutia quality values (for BIT use, see section 4.9), is ONGOING MINEX compliant, and because it is was shown in MINEX 04 to yield consistently low error rates in general interoperability situations¹⁸.

We make the following observations.

- From Table 8(a), the complete column of colored cells indicates MX2D and MX2Q would attain compliance with the PIV specification. This confirms the MX2D manufacturer's assertion in August 2006 that their succesful¹⁹ ONGOING MINEX submission, 1E, was indeed a MATCH-ON-CARD algorithm.
- Four other implementations come close to attaining PIV compliance. They are, in decreasing order of accuracy, MX2T, MX2O, MX2P, and MX2N. The false non-match rates exceed the required 0.01 limit for some generators. Three of these fail with just one template generator, 1D, which produces minutia templates that yield higher than average error rates in the ONGOING MINEX program²⁰ This less than ideal behavior is likely a consequence of differing relative sizes of the templates some minutia generators are more verbose than others and this difference is a known cause of interoperability problems [3]. In any case this specific issue and the variations associated with cross-vendor interoperability are both worthy of further investigation and appropriate standardization efforts.
- \triangleright Tables 9(a) and 9(b) shows that the MX2D implementation would achieve the same FNMR ≤ 0.01 criterion at FMR = 0.001 but not at FMR = 0.0001.
- ▷ The MX2D algorithm produces an order of magnitude fewer false matches than any other algorithm for a given FNMR. That is column MX2D of Table 9(b) (FMR= 10^{-4}) is close to column MX2Q of 9(a) (FMR= 10^{-3}).
- ▷ More generally FNMR values are between two and four times higher at FMR = 0.0001 than at 0.01.
- As documented previously [8, 7, 9] interoperable error rates are higher when three companies are involved (one for the reference template, another for the verification template, and a third for the matcher provider). This is evident in, for example, Table 8 where the native (i.e. single-vendor) combinations (A, MX2T[†]) and (D, MX2D) give the lowest MINEX II error rates of 0.0014 and 0.0015 respectively. Cross-supplier error rates are higher than native because of systematic inconsistencies between implementations on which minutiae are true, false, and missed, and on local placement of minutiae.

4.5 The meaning of PIV compliance

For the many reasons noted on page 3, the error rates measured in large scale offline tests using archival data are not specifically representative of any particular application²¹.

However single-image matching evaluations, conducted on massive archival data sets, are extremely valuable for:

- ▷ fair and repeatable tests,
- ▷ comparative assessments of accuracy,
- ▷ assessing compliance to a dataset-specific performance threshold, and
- ▷ for testing conformance to the standard.

MX2D = Sagem Morpho
MX2I = Oberthur / id3
MX2N = Gemalto / Innovatrix
MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

¹⁸In the the Scenario 2 results of the MINEX 04 supplemental http://fingerprint.nist.gov/minex04/minex_scenario2.pdf, many matchers exhibited low error rates when templates from the D generator were matched against arbitrary others.

¹⁹See http://fingerprint.nist.gov/minex/QPL.html

²⁰The full table of error rates is linked from http://fingerprint.nist.gov/minex under "Test Results".

²¹Except possibly the US-VISIT application, because MINEX II used its images.

y specificati
Compliance to the PIV interoperability
e PIV inte
iance to the
\mathbf{O}
Table 8

templates produced by the generator identified in the row, against corresponding POE templates from the MX2D generator. Shaded cells indicate compliance with the PIV error rate specification, FNMR \leq 0.01 at FMR \leq 0.01. The two rightmost columns refer, respectively, to the use of the MX2N and MX2T matchers with the MX2N and MX2T template generators Sum-fused two-finger FNMR values at FMR = 0.01, 0.001 for the interoperable case in which the MINEX II matcher identified in the column compares left and right index finger BVA instead of the MX2D default. The \dagger and the yellow cell shading serve only to emphasize this point. ion.

	x = 0.01
	AR at FMR
•	(a) FNMR

									,								
Nfing						Column	= MATCH-	Column = $MATCH-ON-CARD$ algorithm, Row = INCITS 378 generator	algorithm	ROW = IN	ICITS 378	generator					
2	MX2D	MX2E	MX2G	MX2H	MX2I	MX2J	MX2K	MX2M	MX2N	MX20	MX2P	MX2Q	MX2R	MX2S	MX2T	MX2N [†]	$MX2T^{\dagger}$
A	0.0038	0.0055	0.0427	0.0324	0.0140	0.0146	0.0156	0.0399	0.0073	0.0041	0.0048	0.0047	0.0466	0.0523	0.0016	0.0127	0.0014
В	0.0020	0.0070	0.0168	0.0159	0.0080	0.0082	0.0086	0.0207	0.0066	0.0037	0.0041	0.0030	0.0356	0.0416	0.0031	8600.0	0.0053
J	0.0030	0.0112	0.0237	0.0231	0.0118	0.0119	0.0128	0.0270	0.0095	0.0056	0.0056	0.0035	0.0482	0.0561	0.0065	0.0101	0.0126
D	0.0015	0.0029	0.0105	0.0066	0.0046	0.0046	0.0048	0.0156	0.0038	0.0021	0.0025	0.0023	0.0175	0.0197	0.0013	0.0092	0.0030
ш	0.0040	0.0055	0.0195	0.0143	0.0093	0.0096	0.0102	0.0514	0.0063	0.0041	0.0044	0.0040	0.0343	0.0387	0.0026	0.0078	0.0034
н	0.0030	0.0112	0.0234	0.0225	0.0115	0.0117	0.0125	0.0271	0.0094	0.0055	0.0056	0.0035	0.0481	0.0557	0.0066	0.0102	0.0126
U	0.0025	0.0080	0.0205	0.0152	0.0102	0.0105	0.0083	0.0310	0.0079	0.0042	0.0044	0.0031	0.0439	0.0508	0.0041	0.0099	0.0069
z	0.0049	0.0121	0.0224	0.0168	0.0116	0.0118	0.0123	0.0343	0.0114	0.0069	0.0059	0.0050	0.0499	0.0561	0.0063	0.0146	0.0094
1C	0.0030	0.0054	0.0254	0.0194	0.0087	0.0088	0.0092	0.0425	0.0049	0.0031	0.0040	0.0036	0.0314	0.0359	0.0022	0.0044	0.0036
1D	0.0052	0.0201	0.0315	0.0267	0.0177	0.0181	0.0190	0.0354	0.0147	0.0103	0.0102	0.0055	0.0611	0.0688	0.0128	0.0154	0.0211
1F	0.0046	0.0140	0.0315	0.0248	0.0158	0.0162	0.0170	0.0392	0.0126	0.0075	0.0077	0.0052	0.0548	0.0618	0.0075	0.0166	0.0096
1G	0.0046	0.0140	0.0315	0.0249	0.0158	0.0162	0.0170	0.0393	0.0126	0.0075	0.0077	0.0052	0.0548	0.0619	0.0075	0.0166	0.0096
1]	0.0032	0.0132	0.0272	0.0210	0.0133	0.0133	0.0140	0.0270	0.0087	0.0048	0.0075	0.0043	0.0484	0.0633	0.0086	0.0114	0.0188
1L	0.0023	0.0058	0.0201	0.0146	0.0093	0.0096	0.0101	0.0295	0.0057	0.0031	0.0040	0.0033	0.0355	0.0417	0.0023	0.0084	0.0034
1M	0.0022	0.0056	0.0197	0.0151	0.0071	0.0071	0.0074	0.0268	0.0064	0.0039	0.0038	0.0030	0.0474	0.0538	0.0031	0.0095	0.0062
1N	0.0038	0.0123	0.0290	0.0228	0.0134	0.0136	0.0143	0.0312	0.0077	0.0049	0.0064	0.0044	0.0485	0.0557	0.0062	0.0074	0.0114
1T	0.0022	0.0039	0.0174	0.0130	0.0078	0.0079	0.0060	0.0306	0.0048	0.0029	0.0030	0.0027	0.0246	0.0275	0.0019	0.0052	0.0036
1Υ	0.0020	0.0046	0.0166	0.0124	0.0079	0.0080	0.0061	0.0274	0.0055	0.0033	0.0034	0.0028	0.0426	0.0482	0.0025	0.0088	0.0049
2A	0.0030	0.0112	0.0237	0.0231	0.0118	0.0119	0.0128	0.0270	0.0095	0.0056	0.0056	0.0035	0.0482	0.0561	0.0065	0.0101	0.0126

Generators	IBIA	Ð	00170A47	000D088E	00020004	001D0100	00310100	00350A01	00118201	00180406	000C0D60	000B0100	00340035	000A0035	00300258	002E0101	003B0101	003C0101	00310101	003B0102	00430011
npliant (NIST	Ð	А	в	U	D	ш	ц	U	z	1C	1D	1F	1G	1J	1L	1M	1N	1T	1Υ	2A
(b) ONGOING MINEX Compliant Generators	Fingerprint	Vendor	Cogent	Dermalog	Bioscrypt	Sagem Morpho	Neurotechnologija	Innovatrics	NEC	Cross Match Technologies	L1/Identix	Precise Biometrics	XTec	SecuGen	BIO-key International	Motorola	Aware	Sonda Technologies	Neurotechnologija	Aware	ImageWare

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs

MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

	generators instead of		gen	generators instead of		e MX2D d	efault. The	e † and the	ne † and the yellow cell ((a) FNMR at FMR = 0.001	the MX2D default. The † and the yellow cell shading serve only to emphasize this point. (a) FNMR at FMR = 0.001	serve only	y to emph	asize this	point.		the MX2D default. The † and the yellow cell shading serve only to emphasize this point. (a) FNMR at FMR = 0.001	
Nfing						Column		= MATCH-ON-CARD	algorithm	algorithm, Row = INCITS 378 generator	JCITS 378	generator					
2	MX2D	MX2E	MX2G	MX2H	MX2I	MX2J	MX2K	MX2M	MX2N	MX2O	MX2P	MX2Q	MX2R	MX2S	MX2T	MX2N [†]	$MX2T^{\dagger}$
A	0.0068	0.0105	0.0765	0.0726	0.0325	0.0343	0.0365	0.0808	0.0131	0.0082	0.0110	0.0108	0.0892	0.0996	0.0037	0.0225	0.0030
в	0.0036	0.0125	0.0373	0.0291	0.0178	0.0181	0.0192	0.0479	0.0114	0.0074	0.0091	0.0073	0.0663	0.0775	0.0061	0.0160	0.0111
J	0.0053	0.0190	0.0518	0.0420	0.0247	0.0255	0.0270	0.0589	0.0156	0.0108	0.0121	0.0083	0.0892	0.1006	0.0119	0.0160	0.0225
D	0.0026	0.0053	0.0222	0.0154	0.0099	0.0098	0.0102	0.0342	0.0064	0.0041	0.0055	0.0049	0.0334	0.0373	0.0026	0.0149	0.0060
ш	0.0069	0.0099	0.0395	0.0310	0.0186	0.0193	0.0203	0.0956	0.0113	0.0079	0.0092	0.0087	0.0663	0.0729	0.0055	0.0129	0.0075
ц	0.0054	0.0189	0.0507	0.0404	0.0241	0.0249	0.0263	0.0586	0.0154	0.0106	0.0121	0.0083	0.0887	0.0999	0.0117	0.0162	0.0227
IJ	0.0046	0.0135	0.0364	0.0328	0.0207	0.0215	0.0227	0.0673	0.0141	0.0089	0.0099	0.0077	0.0825	0.0945	0.0077	0.0168	0.0144
z	0.0084	0.0197	0.0389	0.0352	0.0228	0.0234	0.0243	0.0717	0.0188	0.0128	0.0127	0.0116	0.0857	0.0959	0.0120	0.0237	0.0176
1C	0.0055	0.0092	0.0446	0.0423	0.0239	0.0250	0.0265	0.0822	0.0093	0.0059	0.0083	0.0080	0.0602	0.0684	0.0046	0.0075	0.0083
1D	0.0094	0.0323	0.0624	0.0536	0.0339	0.0351	0.0367	0.0710	0.0235	0.0180	0.0199	0.0123	0.0988	0.1102	0.0212	0.0245	0.0354
1F	0.0087	0.0237	0.0531	0.0498	0.0306	0.0315	0.0332	0.0798	0.0202	0.0138	0.0158	0.0120	0.0964	0.1081	0.0135	0.0270	0.0173
1G	0.0087	0.0238	0.0531	0.0498	0.0307	0.0316	0.0332	0.0799	0.0202	0.0138	0.0158	0.0120	0.0964	0.1081	0.0136	0.0270	0.0174
1]	0.0056	0.0216	0.0476	0.0378	0.0265	0.0273	0.0230	0.0565	0.0137	0.0084	0.0147	0.0097	0.0815	0.1058	0.0142	0.0177	0.0321
1L	0.0044	0.0106	0.0357	0.0325	0.0192	0.0199	0.0209	0.0608	0.0102	0.0064	0.0086	0.0078	0.0695	0.0802	0.0048	0.0143	0.0070
1M	0.0039	0.0099	0.0341	0.0311	0.0192	0.0196	0.0167	0.0566	0.0108	0.0073	0.0079	0.0065	0.0917	0.1029	0.0063	0.0156	0.0130
1N	0.0067	0.0208	0.0529	0.0510	0.0279	0.0289	0.0302	0.0631	0.0134	0.0093	0.0129	0.0097	0.0840	0.0963	0.0105	0.0120	0.0194
1T	0.0042	0.0071	0.0310	0.0281	0.0164	0.0169	0.0177	0.0617	0.0081	0.0055	0.0064	0.0060	0.0468	0.0520	0.0040	0.0088	0.0083
1Υ	0.0039	0.0085	0.0300	0.0272	0.0165	0.0169	0.0177	0.0573	0.0091	0.0063	0.0073	0.0062	0.0835	0.0934	0.0049	0.0143	0.0102
2A	0.0053	0.0190	0.0518	0.0420	0.0247	0.0255	0.0270	0.0589	0.0156	0.0108	0.0121	0.0083	0.0892	0.1006	0.0119	0.0160	0.0225
							q)) FNMR at	(b) FNMR at FMR = 0.0001	001							
Nfing						Column	= MATCH	-ON-CARD	algorithm	= MATCH-ON-CARD algorithm. Row = INCITS 378 generator	ICITS 378	generator					
2	MX2D	MX2F.	MX2G	MX2H	MX2I	MX2I	MX2K	MX2M	MX2N	MX20	MX2P	MX20	MX2R	MX2S	MX2T	MX2N [†]	MX2T [†]
A	0.0116	0.0177	0.1310	0.1225	0.0701	0.0738	0.0777	0.1394	0.0213	0.0151	0.0235	0.0230	0.1535	0.1654	0.0079	0.0373	0.0059
В	0.0061	0.0205	0.0632	0.0512	0.0366	0.0323	0.0339	0.0901	0.0183	0.0129	0.0177	0.0149	0.1113	0.1285	0.0126	0.0241	0.0208
J	0.0088	0.0300	0.0850	0.0709	0.0435	0.0447	0.0468	0.1061	0.0247	0.0176	0.0225	0.0171	0.1414	0.1585	0.0225	0.0247	0.0425
D	0.0041	0.0085	0.0340	0.0281	0.0176	0.0178	0.0186	0.0647	0.0098	0.0071	0.0101	0.0093	0.0548	0.0602	0.0051	0.0226	0.0114
ы	0.0111	0.0158	0.0652	0.0595	0.0371	0.0384	0.0399	0.1240	0.0194	0.0144	0.0177	0.0168	0.1170	0.1260	0.0103	0.0201	0.0144
F	0.0090	0.0305	0.0837	0.0697	0.0493	0.0508	0.0456	0.1058	0.0246	0.0173	0.0222	0.0167	0.1410	0.1589	0.0222	0.0246	0.0424
U	0.0080	0.0209	0.0622	0.0559	0.0400	0.0414	0.0372	0.1222	0.0230	0.0163	0.0191	0.0163	0.1383	0.1552	0.0152	0.0275	0.0260
Z	0.0142	0.0297	0.0720	0.0583	0.0433	0.0446	0.0402	0.1239	0.0286	0.0219	0.0230	0.0216	0.1392	0.1524	0.0208	0.0364	0.0311
1C	0.0086	0.0147	0.0784	0.0720	0.0409	0.0425	0.0445	0.1373	0.0148	0.0103	0.0157	0.0151	0.1078	0.1191	0.0092	0.0117	0.0177
1D	0.0154	0.0460	0.0894	0.0857	0.0553	0.0571	0.0596	0.1214	0.0361	0.0283	0.0330	0.0222	0.1458	0.1598	0.0366	0.0365	0.0586
1F	0.0140	0.0358	0.0878	0.0812	0.0502	0.0519	0.0543	0.1362	0.0310	0.0235	0.0292	0.0242	0.1507	0.1673	0.0239	0.0399	0.0292
1G	0.0140	0.0359	0.0879	0.0813	0.0503	0.0520	0.0544	0.1363	0.0310	0.0236	0.0292	0.0242	0.1508	0.1673	0.0240	0.0400	0.0293
1J	0.0087	0.0331	0.0718	0.0649	0.0442	0.0458	0.0477	0.1001	0.0210	0.0143	0.0259	0.0198	0.1245	0.1577	0.0247	0.0259	0.0549
1L	0.0075	0.0178	0.0625	0.0564	0.0333	0.0346	0.0360	0.1086	0.0166	0.0118	0.0168	0.0160	0.1158	0.1339	0.0095	0.0227	0.0144
1M	0.0067	0.0160	0.0583	0.0530	0.0318	0.0326	0.0341	0.1003	0.0173	0.0125	0.0151	0.0125	0.1560	0.1741	0.0116	0.0241	0.0250
1N	0.0114	0.0312	0.0919	0.0862	0.0482	0.0498	0.0519	0.1108	0.0212	0.0146	0.0227	0.0195	0.1305	0.1479	0.0184	0.0184	0.0338
1T	0.0068	0.0120	0.0612	0.0485	0.0281	0.0289	0.0302	0.1065	0.0126	0.0093	0.0130	0.0120	0.0816	0.0888	0.0077	0.0138	0.0175
1Y	0.0062	0.0133	0.0577	0.0470	0.0278	0.0285	0.0300	0.1016	0.0148	0.0106	0.0136	0.0121	0.1383	0.1511	0.0099	0.0222	0.0211
2A	0.0088	0.0300	0.0850	0.0709	0.0435	0.0447	0.0468	0.1061	0.0247	0.0176	0.0225	0.0171	0.1414	0.1585	0.0225	0.0247	0.0425

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent MX2H = Oberthur / id3 MX2M = Giesecke - Devrient MX2Q = Oberthur / id3

index finger BVA templates produced by the generator identified in the row, against corresponding POE templates from the MX2D generator. Shaded cells indicate compliance with the PIV Sum-fused two-finger FNMR values at FMR = 0.001 (above) and 0.0001 (below) for the interoperable case in which the MINEX II matcher identified in the column compares left and right Table 9: Compliance beyond the PIV interoperability specification.

In particular, the offline nature of the ONGOING MINEX and MINEX II tests makes them suitable for assessing the core accuracy and interoperability of minutia matching algorithms. That is, the tests are suitable for exposing implementations that are improperly implementing the underyling INCITS 378 and ISO/IEC 19794-2 COMPACT CARD minutiae standards.

Thus, while the MINEX trials are necessary for qualification of implementations, and they effectively support operations, they are not sufficient for prediction of fielded performance.

4.6 One and two finger matching

This report contains performance estimates for one and two-finger authentication. The single-finger results are obtained by pooling the scores from the left and right index finger comparisons as though they were from different individuals. The performance estimates are therefore representative of single-finger verification applications in which users choose to present either left or right index fingers in equal proportion. This report does not assess the effect of multiple verification attempts because it uses archived datasets with only two impressions per finger. Note, however, that the images were collected using the auto-capture paradigm in which a number of images were collected over an interval of a few seconds, and the best one (according to a commercial quality assessment algorithm) retained.

Two mechanisms were used for combining two-finger matching scores: score-level fusion, and decision-level fusion.

▷ Score Fusion: The fused score is simply the sum of the left and right comparison scores:

$$s_{ij} = s_{ij}^{(R)} + s_{ij}^{(L)}$$
(6)

where i and j denote the i-th enrolled image and the j-th authentication sample and s is the scalar output of a matcher. This *sum-rule* is a simple yet powerful method for multi-sample fusion, is ubiquitous in the literature [14, 10], and has long had theoretical recommendation [11]. The fused score is compared against a threshold, and error rates are again computed using eqs. 4 and 2.

The use of fusion, however, has significant implications. In sum-rule fusion, FNMR rates drop substantially for a given FMR but there is the attendant requirement to *always* acquire and match samples from both fingers. This will generally double the time, the exception being if two sensors are available and used simultaneously, whence the total time τ_T

$$\tau_T = \max(\tau_1, \tau_2) \tag{7}$$

where we expect the primary and secondary²² finger times would be expected to be about the same, i.e. $\tau_1 \approx \tau_2$. These times would include the user-sensor interaction, capture, minutiae extraction, template generation, communication with smartcard, matching, and return of the result.

If, as is more common, the acquisition is sequential, then the total time, τ_T for sum-rule fusion will be

$$\tau_T = \tau_1 + \tau_2 \tag{8}$$

This approach turns out to be accurate but time consuming for users.

Decision ("OR") Fusion: The more efficient alternative is to only conditionally acquire and compare the second finger. That is, if recognition of a genuine user or impostor is unsuccessful with the first finger, then the second finger is acquired and matched. This constitutes decision-level "OR" fusion. The idea is that many genuine users will require only a single finger to authenticate while the FMR security objective is met after one or two fingers are used. We analyse the time-savings by adopting the model of the 2006 NIST study[15] in which the total transaction time per genuine user will be

$$\tau_T = \tau_1 + \tau_2 \text{FNMR}_1(t_1) + \tau_r \text{FNMR}_T(t_1, t_2)$$
(9)

²²We avoid the handedness issue here. In all the analyses we assume each user is righthanded and presents that finger first. This is not true - the natural incidence of right-handedness has been reported as 88%[12] but there are wide geographic and social variations, and a tendency toward righthandness over an individuals lifetime - and is relevant only because left-finger verification gives somewhat larger error rates than right.

MX2D :	= Sagem Morpho	
MX2I =	Oberthur / id3	
MX2N :	= Gemalto / Innovatrix	
MX2R =	- Gemalto / Micro Packs	

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

	Thres	holds	Finger 1	accuracy	Overall	accuracy	Transaction
Matcher	t_1	t_2	FMR ₁	FNMR ₁	FMR_T	$FNMR_T$	time, τ_T (s)
MX2D	6298	6298	0.0005	0.0306	0.0010	0.0045	4.59
MIA2D	6118	6539	0.0007	0.0289	0.0010	0.0044	4.57
MX2E	6338	6338	0.0005	0.0594	0.0010	0.0146	5.67
MALE	6178	6618	0.0007	0.0566	0.0010	0.0146	5.66
MX2G	9	9	0.0004	0.1501	0.0007	0.0466	9.09
MA2G	8	10	0.0008	0.1311	0.0009	0.0454	8.87
MX2H	10	10	0.0004	0.1383	0.0008	0.0416	8.57
ΜΛ2Π	9	11	0.0007	0.1211	0.0009	0.0401	8.34
MX2I	9	9	0.0003	0.1025	0.0007	0.0272	7.06
IVIA2I	8	10	0.0007	0.0851	0.0008	0.0261	6.86
MX2J	9	9	0.0003	0.1043	0.0006	0.0280	7.15
IVIA2J	8	9	0.0006	0.0866	0.0010	0.0241	6.69
MX2K	9	9	0.0003	0.1075	0.0006	0.0293	7.28
MAZK	8	9	0.0006	0.0893	0.0009	0.0251	6.80
MX2M	11	11	0.0001	0.2202	0.0004	0.0829	12.78
10172101	10	11	0.0007	0.1594	0.0010	0.0629	10.61
MX2N	11448	11448	0.0005	0.0511	0.0009	0.0112	5.32
IVIA2IN	11210	11527	0.0006	0.0487	0.0010	0.0108	5.27
MX2O	11683	11683	0.0005	0.0406	0.0010	0.0084	5.00
MA20	11442	11992	0.0006	0.0382	0.0010	0.0083	4.97
MX2P	3913	3913	0.0005	0.0570	0.0011	0.0117	5.39
IVIA2F	3822	4131	0.0006	0.0545	0.0010	0.0121	5.42
MX2O	4005	4005	0.0005	0.0515	0.0011	0.0097	5.18
MIA2Q	3933	4245	0.0006	0.0497	0.0010	0.0101	5.21
MX2R	834	834	0.0005	0.1983	0.0008	0.0909	13.37
MAZK	801	791	0.0006	0.1916	0.0010	0.0856	12.85
MX2S	882	882	0.0005	0.2208	0.0008	0.1054	14.81
111723	855	825	0.0006	0.2149	0.0010	0.0992	14.22
MX2T	795	795	0.0005	0.0311	0.0009	0.0073	4.84
	776	808	0.0006	0.0299	0.0010	0.0071	4.82

Table 10: Simulated expected transaction time for OR-fused two-finger verification.

For each matcher, there are two rows. The first gives the decision level fusion result for equal thresholds $(t_1 = t_2)$ with t_1 set to the lowest value for which FMR $(t_1) \le 0.0005$. The second row is the result of a minimum cost search over all possible (t_1, t_2) combinations. The last column gives the expected *transaction* time in seconds for the time model given in equation 9. The reference and verification templates are from MX2D and B respectively.

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

(b) Perturbed similarity scores

		(a) Kaw	similarity	scores				(b) renurb	eu sinnar	ity scores		
	Single	finger	OR f	usion	SUM	fusion		Single	finger	OR f	usion	SUM	fusion
Matcher	FMR	FNMR	FMR	FNMR	FMR	FNMR	Matcher	FMR	FNMR	FMR	FNMR	FMR	FNMR
MX2D	0.0005	0.0386	0.0010	0.0045	0.0010	0.0036	MX2D	0.0005	0.0386	0.0010	0.0045	0.0010	0.0036
MX2E	0.0005	0.0753	0.0010	0.0146	0.0010	0.0125	MX2E	0.0005	0.0753	0.0010	0.0146	0.0010	0.0125
MX2G	0.0002	0.1836	0.0007	0.0466	0.0007	0.0373	MX2G	0.0005	0.1579	0.0010	0.0435	0.0010	0.0343
MX2H	0.0002	0.1730	0.0008	0.0416	0.0010	0.0291	MX2H	0.0005	0.1484	0.0010	0.0389	0.0010	0.0287
MX2I	0.0002	0.1353	0.0007	0.0272	0.0009	0.0178	MX2I	0.0005	0.1095	0.0010	0.0244	0.0010	0.0173
MX2J	0.0001	0.1386	0.0006	0.0280	0.0008	0.0181	MX2J	0.0005	0.1106	0.0010	0.0246	0.0010	0.0174
MX2K	0.0001	0.1425	0.0006	0.0293	0.0008	0.0192	MX2K	0.0005	0.1121	0.0010	0.0251	0.0010	0.0180
MX2M	0.0000	0.3016	0.0004	0.0829	0.0009	0.0479	MX2M	0.0005	0.2093	0.0010	0.0678	0.0010	0.0471
MX2N	0.0005	0.0619	0.0010	0.0108	0.0010	0.0114	MX2N	0.0005	0.0618	0.0010	0.0108	0.0010	0.0114
MX2O	0.0005	0.0512	0.0010	0.0083	0.0010	0.0074	MX2O	0.0005	0.0512	0.0010	0.0083	0.0010	0.0074
MX2P	0.0005	0.0692	0.0010	0.0120	0.0010	0.0091	MX2P	0.0005	0.0690	0.0010	0.0120	0.0010	0.0091
MX2Q	0.0005	0.0631	0.0010	0.0102	0.0010	0.0073	MX2Q	0.0005	0.0629	0.0010	0.0102	0.0010	0.0073
MX2R	0.0005	0.2267	0.0010	0.0856	0.0010	0.0663	MX2R	0.0005	0.2264	0.0010	0.0855	0.0010	0.0662
MX2S	0.0005	0.2494	0.0010	0.0995	0.0010	0.0775	MX2S	0.0005	0.2492	0.0010	0.0995	0.0010	0.0775
MX2T	0.0005	0.0404	0.0010	0.0071	0.0010	0.0061	MX2T	0.0005	0.0403	0.0010	0.0071	0.0010	0.0061

(a) Raw similarity scores

Table 11: Use of the second finger.

Accuracy of single-finger, OR-fused ($t_1 = t_2$) and SUM-fused two-finger verification. The threshold is fixed to target a single-finger false match of 0.0005. This is not always achieved (FMR in second column of Table 11(a)) due to discretized similarity scores. The problem disappears in Table 11(b) via addition of noise as described in sec. 4.8. This produces the targeted FMR and reduces FNMR. Cells are shaded when matching of the the reference (MX2D) and verification (B) templates achieves the PIV accuracy specification.

where

- t_1 and t_2 are the first and second finger matcher thresholds,
- τ_r is the time taken for the resolution of cases where both fingers fail to match²³,
- FNMR₁(t_1) is the fraction of genuine users whose primary fingers are incorrectly rejected, and
- FNMR $_T(t_1, t_2)$ is the fraction of genuine users for whom both fingers are rejected.

Note that in the results that follow we assume the single finger attempt time is fixed for all matchers. This blatantly ignores the card timing measurements of 5 which are less than 1 second for all but MX2M. While our intent is to show only the large effects of accuracy variations on time, we recommend that deployers should include these and other times in any formal or predictive model.

Note that this model assumes that the prior probability of impostors is small enough that their contribution to the aggregate transaction time is negligible.

We conduct two analyses, one in which $t_1 = t_2$, and a second in which the thresholds differ and are optimized to offer greater efficiency while maintaining an FMR objective. The determination of thresholds proceeds empirically: We use a global ²⁴ search to find the (t_1, t_2) pair that minimizes the "cost" function τ_T while satisfying the overall security constraint FMR_T ≤ 0.001 , say.

4.7 Fusion results

We arbitrarily set $\tau_1 = 4$ seconds (i.e. the time for acquisition plus MATCH-ON-CARD processing of the first finger), $\tau_2 = 6$ s (i.e. the times for a prompt, switch, acquisition plus processing of the second finger), and $\tau_r = 90$ s (remedial authentication). NIST advances this model and set of parameters **only as an example** - any given operation should tailor

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

²³For example, authentication by a supervisor or via an alternative biometric modality.

²⁴A global search for MX2D and MX2E was not possible because the large number of unique scores makes the naïve computation too costly. Instead we conducted a local search over a threshold range of $t_0 \pm 4000$ in increments of 5 about the point $t_0 = \text{FMR}^{-1}(0.0005)$. This entails 400^2 function evaluations.

such analysis specifically - and besides the actual τ values are irrelevant up to a multiplier. The result is a verification time that in many cases is exactly four seconds, but for some extends to 10 or 100 seconds.

For an overall FMR target of 0.001, we execute the model of eq. 9 for cases where $t_1 = t_2 = FMR^{-1}(0.0005)$ and where $t_1 \neq t_2$ are solved for to minimize cost. Table 10 shows the results from which the following observations can be made.

- ▷ Row one, column five shows, for MX2D, that the fraction of users needing to present a second finger is 3.06% when the thresholds are set to be equal.
- ▷ Row two, column five shows that this fraction drops to 2.89% when the thresholds are allowed to float. The efficiency saving is larger for other implementations.
- \triangleright This is achieved by lowering t_1 and elevating t_2 . An added benefit is that the achieved overall FMR in column 6 is closer to the target FMR than for equal thresholds.

Table 11 summarizes the situation in which $t_1 = t_2 = t$ are set to achieve a target FMR of 0.0005 and users authenticate with their primary finger and only present their secondary finger if the first was rejected. Referring to Table 11(b), the results are:

- ▷ The FMR values are almost exactly doubled by allowing use of the second finger;
- ▷ The FNMR values are reduced by factors between five and eleven;
- ▷ Together these differences are in agreement with the single-finger vs. sum-fused DET plots of Figure 1;
- ▷ The cells shaded green indicate that PIV compliance is possible with decision level fusion (at least for this particular matcher and template generator combination);
- ▷ The operational relevance of decision-level fusion is an improvement in efficiency: Not all users will have to present a secondary finger. In the case of the MX2D matcher and the particular template generator combination, only 3.86% of genuine users will have to submit their secondary finger.
- ▷ Score level fusion is slightly more accurate than decision level fusion.

None of the comparisons involved impostors presenting left as right, or vice versa.

4.8 Effect of discrete similarity scores

The effect of tied scores, as demonstrated in the latter rows of Table 11(a), is the failure to achieve the target FMR value of 0.0005. One remedy is to break ties by adding small amounts of noise to all scores:

$$s' = s + U(0, d/50) \tag{10}$$

where U is a uniformly distributed noise process of zero mean and width d/50. The value of d is

$$d = \min_{i,j} |s_i - s_j| \tag{11}$$

i.e. the smallest difference between any two matcher scores.

The effect of using equation 10 is to allow precise realization of the (higher) target FMR value, and to thereby reduce FNMR. This is evident by comparing values in columns four and five of Table 11(a) with the corresponding elements in Table 11(b).

MX2D = Sagem Morpho
MX2I = Oberthur / id3
MX2N = Gemalto / Innovatrix
MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

Matcher	Generator		Comparisons		Pruning	FMR	FNMR
	Ref	Verify	Which Number of		Priority		
	All comparisons			2747804	Quality then radial	0.0018	0.0804
			Either or both templates have ≥ 61 minutiae	832225	Quality then radial	0.0013	0.1210
			Either or both templates have ≥ 61 minutiae	832225	Radial only	0.0013	0.1210
				2747804	Quality then radial	0.0018	0.0804
	MX2D	В	Either or both templates have \geq 70 minutiae	194782	Quality then radial	0.0010	0.1817
MX2I			Either or both templates have \geq 70 minutiae	194782	Radial only	0.0010	0.1816
101/121			All comparisons	2747804	Quality then radial	0.0014	0.0574
	MX2D MX2D		Either or both templates have ≥ 61 minutiae	491061	Quality then radial	0.0009	0.0612
			Either or both templates have ≥ 61 minutiae	491061	Radial only	0.0011	0.0693
	MX2D MX2D		All comparisons	2747804	Quality then radial	0.0014	0.0574
			Either or both templates have \geq 70 minutiae	79744	Quality then radial	0.0008	0.0769
			Either or both templates have \geq 70 minutiae	79744	Radial only	0.0012	0.0992

(a) Quality-assisted minutiae removal

(b) Center-assisted minutiae removal

Matcher	Generator		Comparisons		Pruned	FMR	FNMR
	Ref	Verify	Which	Number of	About		
			All comparisons	2747804	Dedicated (x_c, y_c)	0.0018	0.0803
	MX2Dq0	В	Either or both templates have \geq 61 minutiae	832225	Dedicated (x_c, y_c)	0.0013	0.1210
	1		Either or both templates have ≥ 61 minutiae	832225	Center of Mass	0.0013	0.1209
			All comparisons	2747804	Dedicated (x_c, y_c)	0.0018	0.0803
	MX2Dq0	В	Either or both templates have \geq 70 minutiae	194782	Dedicated (x_c, y_c)	0.0010	0.1816
MX2I			Either or both templates have \geq 70 minutiae	194782	Center of Mass	0.0010	0.1815
IVI/(21			All comparisons	2747804	Dedicated (x_c, y_c)	0.0015	0.0588
	MX2Dq0 MX2Dq0	MX2Dq0	Either or both templates have ≥ 61 minutiae	491061	Dedicated (x_c, y_c)	0.0011	0.0693
			Either or both templates have \geq 61 minutiae	491061	Center of Mass	0.0012	0.0608
	MX2Dq0	MX2Dq0	All comparisons	2747804	Dedicated (x_c, y_c)	0.0015	0.0588
			Either or both templates have \geq 70 minutiae	79744	Dedicated (x_c, y_c)	0.0012	0.0992
			Either or both templates have \geq 70 minutiae	79744	Center of Mass	0.0015	0.0752

Table 12: Effect of enhanced methods for minutiae removal.

The tables show the effect on FMR and FNMR of using minutia quality values and dedicated centers for removal of minutiae to satisfy MOC algorithm capability constraints. Throughout, the threshold is fixed at the (matcher-specific) value of 7 to give FMR near 0.001. The B generator does not emit quality values (per MINEX 04 requirements), and so its outputs are always pruned radially. In Table 11(a) the dedicated pruning center is used. In Table 11(b) the minutia quality values are zero throughout.

Vendor ID	Num BITs	Min	Max	Sort Order
MX2D	2	3	128	None Given (0x00)
MX2E	2	3	128	None Given (0x00)
MX2F	1	12	60	Y-X Ascending (0x09)
MX2G	1	12	60	Y-X Ascending (0x09)
MX2H	1	12	60	Y-X Ascending (0x09)
MX2I	1	12	60	Y-X Ascending (0x09)
MX2J	1	12	60	Y-X Ascending (0x09)
MX2K	1	12	60	Y-X Ascending (0x09)
MX2M	1	3	60	None Given (0x00)
MX2N	2	0	80	Y-X Ascending (0x09)
MX2O	2	0	80	Y-X Ascending (0x09)
MX2P	1	12	60	Y-X Ascending (0x09)
MX2Q	1	2	80	Y-X Ascending (0x09)
MX2R	2	0	64	Y-X Ascending (0x09)
MX2S	2	0	64	Y-X Ascending (0x09)
MX2T	2	0	55	None Given (0x00)

Table 13: BIT parameters from the MINEX II cards. In all cases, when a vendor's card had both BITs, they were identical.

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

4.9 Effect of using minutia quality values

The original MINEX 04 test required the minutia quality byte of the INCITS 378 record to be set to zero. This was done because it was considered that vendor values would be non-interoperable. In MINEX II, this requirement was dropped to allow quality values to be used to direct removal of minutiae. This process is part of the INCITS 378 to ISO/IEC 19794-2 COMPACT CARD conversion and is needed to strip excess minutiae from larger templates to satisfy the limits communicated by the card in its ISO/IEC 7816 BIT. The BIT parameters are listed in Table 13.

The evaluation plan [9] augmented the INCITS 378 definition of minutia quality to state that quality should be related to likelihood of the minutia being a true minutia (as opposed to a local ridge clarity measure, for example).

Without quality values, the simplest mechanism for satisfying card cabability limits is to remove those with the largest radial distance from the center, as alluded to in ISO/IEC 19794-2:2005.

$$r^{2} = (x - x_{c})^{2} + (y - y_{c})^{2}$$
(12)

This procedure was described in the evaluation plan [9]. To test the effectiveness of quality-directed pruning we applied only one of the 60-minutiae MATCH-ON-CARD implementations, MX2I. We generated a set of templates using the quality enabled MX2D minutia detector. We matched those against both MX2D templates and no-quality-value B templates. We then stripped the quality values from the MX2D templates, and rematched.

From the results shown in Table 11(a) the following observations can be made:

- ▷ The FNMR values are higher, and the FMR values are lower, when either or both of the input templates contain more than 60 minutiae i.e. $\max(N_r, N_v) > 60$. These effects are larger for very large templates i.e. $\max(N_r, N_v) > 70$.
- ▷ The quality-then-radial approach is superior to the radial-only method (i.e. eq. 12) only when both templates have minutia quality values (i.e. the MX2D-MX2D rows in the bottom half of the Table 11(a)). Referring to the last two lines, the effect is to reduce FNMR ($0.0992 \rightarrow 0.0769$).
- \triangleright When one template is generated with quality values (MX2D) but the other does not (B) there is no gain in accuracy. Referring to the second block of three rows the effect on FNMR (0.1817 \rightarrow 0.1816) is negligible:

4.10 Effect of using dedicated centers for pruning

The MINEX II API[9] allowed the template generator to return the coordinates of a point about which minutiae should be removed. This was suggested by industry as an improvement over the use of the center-of-mass.

To assess whether this dedicated center was worthwhile, we again applied matcher MX2I to MX2D and B templates. The quality values were set to zero in all MX2D templates. Equation 12 was applied using either the specific (x_c, y_c) or the center of mass $(1/N \sum x_i, 1/N \sum y_i)$.

The results are shown in Table 11(b). We make the following observations.

- ▷ As with quality assisted pruning, there is essentially no change in accuracy when MX2D templates are compared with B templates.
- ▷ For MX2D-MX2D comparisons, there is a decrease in accuracy when templates are pruned about the dedicated center. Note that the minutia quality values were set to zero because otherwise minutia would be removed on the basis of low quality first and *then* on distance.

The conclusions on minutia removal in the preceding text are weakened by the following.

▷ Only one quality-equipped generator was available (MX2D) in Phase II and it was used with only one other generator (B) and one matcher (MX2I).

MX2D = Sagem Morpho
MX2I = Oberthur / id3
MX2N = Gemalto / Innovatrix
MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

- ▷ The negative result for the MX2D-B combination may be different for other template generators if they tend to produce more or fewer minutiae. This requires further testing.
- ▷ The comparison of templates from the same vendor may be rare in a large federated multivendor interoperable MATCH-ON-CARD application.

The results should not be considered as general until a wider survey of quality-enabled and center-enabled template generators can be conducted.

4.11 Card errors

All cards operated perfectly except that the MX2M card objected to the reference template PUT DATA command on 11 out of 80000 occasions. The error code in each case was 0x6F00.

4.12 Card-SDK differences

With two exceptions, all SDKS and corresponding card-based matching implementations produced identical similarity scores given the same input template pairs. This was measured over 80000 comparisons. Identity of scores is the critical assurance that the on-card and off-card algorithms are identical.

The two exceptions were:

- ▷ MX2G which gave non-identical scores on 49 of 80000 comparisons. These all occured on low-scoring impostor comparisons, and the absolute score difference never exceeded 3. This means that about 0.06% of impostor and approximately 0.02% of genuine comparisons gave different SDK and Card values.
- ▷ Whenever the MX2M SDK produced a similarity score of 7 or below, the MX2M card reported 0. This means that about 84% of impostor and approximately 5% of genuine comparisons gave different SDK and Card values. The consequence of this disparity is that NIST cannot conclude that the same algorithm is in use, and would not test it for compliance to the PIV accuracy specification.

5 MOC timing

5.1 Measurement techniques

For each card submitted, NIST measured the duration of all executions of the following actions.

- ▷ Reference template storage operations made using the PUT_DATA APDU,
- ▷ Template comparisons using the VERIFY APDU which includes the sending of the verification template to the card, and
- ▷ The similarity score retrieval operations made via the GET_DATA APDU.

The time taken to generate the verification template is not included in the above. For the MX2D generator, the median time to convert an in-memory uncompressed greyscale raster image into an INCITS 378 record was 0.094 seconds for the 368x368 pixel POE verification image and 0.172 seconds for the 500x500 pixel BVA enrolment image. For these two datasets, the 99-th percentile times were, 0.11 and 0.19 seconds respectively. These times apply to Xeon-based PCs.

These times were measured by means of the Linux *gettimeofday()* system call. The NIST card test driver wraps each APDU in two such calls, and the interval is obtained by subtraction. This is shown in the driver source code, which may be downloaded and inspected via the NIST open-source server (see BIOMAPP, section 3.7).

MX2D = Sagem Morpho
MX2I = Oberthur / id3
MX2N = Gemalto / Innovatrix
MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent




Figure 2: Times for ISO/IEC 7816 VERIFY commands to complete for all MINEX II cards and broken out for genuine and impostor comparisons. Genuine comparisons are shown in green, impostors in yellow. The scale is logarithmic. The vertical dashed lines extend to the highest and lowest observed values. The blue lines correspond to 0.5s and 1.0s.

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

While the *gettimeofday()* call offers better than microsecond resolution on the platform we used for testing, the measured durations include more than just the elemental card operations. The overhead includes

- ▷ all the calls to the PC/SC library,
- ▷ communication from the card driver process to the PC/SC smartcard daemon, and
- ▷ USB communication.

The effect of these is assumed to be fixed across all MATCH-ON-CARD implementations tested. In particular, the host computer was dedicated to the testing of the cards, with only normal operating system related and file system processes running. These processes require very little overhead in terms of overall system resources.

The hardware listed in Appendix A was disclosed to participants before the test. MINEX II did not test other configurations, and while we understand that faster end-to-end times may be possible using alternative hardware and protocols, the timing method used here is fair and consistent for comparison of implementations.

5.2 Comparison timing results

Figure 2 is a boxplot summary of the time taken by the various MATCH-ON-CARD implementations to execute the ISO/IEC 7816 VERIFY command. The plot separates the genuine from impostor comparisons. The colored boxes indicate the interquartile range. The whiskers indicate the extreme values. The plots are derived from 80000 comparisons for each matcher. Of those 5012 correspond to genuine comparisons. Note that the card specifications are not known - NIST did not ask for information related to card processor or memory. It is likely that suppliers submitted their more capable cards to the test. Regarding the VERIFY command, we make the following observations.

- ▷ The most interoperable MATCH-ON-CARD algorithm, MX2D, is neither the slowest, nor the fastest. The median time for its execution of genuine VERIFY command is 0.54 seconds. Only about 1% of the 80000 comparisons exceeds 0.77 seconds.
- ▷ The MX2Q implementation is slower but more accurate than it's MX2P sibling. The former achieves the PIV interoperable accuracy specification; the latter does not.
- ▷ The same speed-accuracy tradeoff applies to the MX2N, MX2O pair. It does not apply to MX2D, MX2E, the latter being the less accurate sibling. However, the variance and worst-case times are reduced.
- ▷ For the fastest implementation, MX2G, the median time for the execution of genuine VERIFY command is 0.18 seconds.
- \triangleright The VERIFY time distributions are approximately Normal (Q-Q plots are linear to beyond $+3\sigma$). However, outliers do occur and these are *not* measurement errors attributable to the testing platform. Instead there are a small number of templates that are problematic for multiple suppliers' matchers. For example, one template involved in the second-slowest MX2D comparison (2.45 seconds) also causes comparisons in excess of two seconds for matchers MX2I, MX2J and MX2K.
- ▷ In all cases, the variance in the duration of the genuine comparisons is larger than that of impostor comparisons.

5.3 Other timing results

We also measured the times required to place a reference template on the card and to retrieve the similarity score from the card. These are summarized as boxplots in Figures 3(a) and 3(b). Both of these are unimportant: population of the card happens once at time of card issuance, and retrieval is a test-specific function, and never part of an operational authentication attempt. The retrieval time is interesting here because it reveals the variation inherent in the card-PC communication for the retrieval of a fixed size data object (8 bytes). Over all matchers, $2\sigma = 0.007$ seconds.

MX2D = Sagem Morpho	MX2E = Sagem Morpho	MX2G = Oberthur / id3	MX2H = Oberthur / id3
MX2I = Oberthur / id3	MX2J = Oberthur / id3	MX2K = Oberthur / id3	MX2M = Giesecke - Devrient
MX2N = Gemalto / Innovatrix	MX2O = Gemalto / Innovatrix	MX2P = Oberthur / id3	MX2Q = Oberthur / id3
MX2R = Gemalto / Micro Packs	MX2S = Gemalto / Micro Packs	MX2T = Gemalto / Cogent	




Figure 3: Times in seconds for ISO/IEC 7816 APDUs for storage of the reference template on the card (above), and for retrieval of the similarity scores from the card (below). Note the logarithmic axis.

MX2D = Sagem Morpho	MX2E = Sagem Morpho	MX2G = Oberthur / id3	MX2H = Oberthur / id3
MX2I = Oberthur / id3	MX2J = Oberthur / id3	MX2K = Oberthur / id3	MX2M = Giesecke - Devrient
MX2N = Gemalto / Innovatrix	MX2O = Gemalto / Innovatrix	MX2P = Oberthur / id3	MX2Q = Oberthur / id3
MX2R = Gemalto / Micro Packs	MX2S = Gemalto / Micro Packs	MX2T = Gemalto / Cogent	

30

6 Non-conformance to the MINEX II specification

The MINEX II test specification worked very well. That is, SDK implementations conformed to both the API, and the cards conformed to the required APDUs. That said, we document below irregularities we had to work around.

1. The Biometric Header Template (BHT), contained within the Biometric Information Template (BIT), has several mandatory fields as required by ISO/IEC 7816-11:2004. Two fields, format owner (TLV tag 0x87) and format type (tag 0x87) are specified in the MINEX II test document as having values 0x0101 and 0x005, respectively. One vendor omitted those fields, with this justification:

The CBEFF info, tags 0x87 and 0x88 within the BHT are actually missing because we believed it was the default value as described in Note 6 of Table C1 of 7816-11.

However, Note 6 in Table C1 of the MINEX II Evaluation Plan[9] refers to the OID of the CBEFF standard body field (tag 0x06) only, not the format owner and format type fields, which are noted as mandatory. This fact was pointed out to the vendor, and we received this response:

You are correct and the note 6 of table C1 applies only to the 0x06 tag in the BIT, not the 0x87 and 0x88 tags in the BHT. Our reading assumed that the logic behind note 6 could also applied to the 0x87 and 0x88 tags in the BHT and that the editor forgot to extend the note 6 to these 2 tags of similar nature. But we can easily add these 2 tags in the next card delivery.

This was done. In order to proceed with testing, we modified the NIST test driver to ignore the absence of these fields. Future testing within the MINEX II framework will require the presence of these fields.

2. Card and Matcher IDs in the TLV objects: The MINEX II test specification defined the APDUs and expected responses for reading card and matcher IDs. The GET DATA instruction code (0xCB) is used, and the Lc field contains a tag list data object (code 0x5C), requesting a single TLV data item to be returned. The requested object ID for the card ID is 0x66, and for the matcher ID is 0x6E.

The MINEX II Evaluation Plan[9] states that the returned data object should be of the form "0x73 06 88 04 <4 byte CBEFF ID>", which is non-conforming with regard to ISO 7816 use of the 0x5C code, in that the returned data object's tag should be the same as that requested. Therefore, the correct response for the card ID is "0x66 08 73 06 88 04 <4 byte card ID>", and for the matcher ID is "0x6E 08 73 06 99 04 <4 byte matcher ID>".

One vendor returned the data object in the correct (i.e. NOT according to the MINEX II document) form; all other cards returned the IDs in the form given in the document. NIST changed the test software to accept either form so testing could proceed. Future versions of the MINEX II will be corrected, and cards should return data objects in the ISO-compliant format.

An improvement to the test specification is to use a single APDU to request both the card and matcher IDs to be returned in the application related data object: The APDU would be the same as currently used for matcher ID: "0x00 CB 3F FF 03 5C 01 6E 00''

The response data object would be: "0x6E 0E 73 0C 88 04 <4 byte card ID> 99 04 <4 byte matcher ID>"

Another alternative is to ask for both card and matcher IDs to be returned in a single response. The APDU would be: "0x00 CB 3f FF 04 5C 02 66 6E"

with this response: "0x66 08 73 06 88 04 <4 byte card ID> 6E 08 73 06 99 04 <4 byte matcher ID>"

MX2D = Sagem Morpho MX2I = Oberthur / id3 MX2N = Gemalto / Innovatrix MX2R = Gemalto / Micro Packs MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

References

- Working Group 1. Standing Document 2 Harmonized Biometric Vocabulary. Technical report, ISO/IEC JTC1 SC37 N1248, November 2005.
- [2] Working Group 5. *ISO/IEC 19795-1 Biometric Performance Testing and Reporting: Principles and Framework*. JTC1 :: SC37, international standard edition, August 2005. http://isotc.iso.org/isotcportal.
- [3] A. Bazin and T. Mansfield. An investigation of minutiae interoperability. In *Proc. Fifth IEEE Workhop on Automated Identification Advanced Technologies*, June 2007. AUTO-ID 2007, Alghero Italy.
- [4] W.-Y. Choi, K. Lee, S.B. Pan, and Y. Chung. Realizable classifiers: Improving performance on variable cost problems. In M. H. Hamza, editor, *BMVC*. ACTA Press, 2004.
- [5] D. Cooper, H. Dang, P. Lee, W. MacGregor, and K. Mehta. Secure Biometric Match-on-Card Feasibility Report. Technical report, National Institute of Standards and Technology, November 2007. Published as NIST Interagency Report 7452.
- [6] J. Campbell et al. *ILO Seafarers' Identity Documents Biometric Testing Campaign Report*. International Labour Organization, Geneva, 2005. http://www.ilo.org/public/english/dialogue/sector/papers/maritime/sid-test-report2.pdf.
- [7] T. Mansfield et al. Research report on minutiae interoperability tests. Technical report, Minutiae Template Interoperability Testing, 2007. http://www.mtitproject.com/DeliverableD62.pdf.
- [8] P. Grother, M. McCabe, C. Watson, M. Indovina, W. Salamon, P. Flanagan, E. Tabassi, E. Newton, and C. Wilson. Performance and Interoperability of the INCITS 378 Fingerprint Template. Technical report, National Institute of Standards and Technology, March 2006. Published as NIST Interagency Report 7296.
- [9] P. Grother and W. Salamon. Minex ii an assessment of iso/iec 7816 card-based match-on-card capabilities - evaluation plan. Technical Report NISTIR 7485, National Institute of Standards and Technology, fingerprint.nist.gov/minexII/, August 2007.
- [10] A. K. Jain, S. Prabhakar, and S. Chen. Combining combining multiple matchers for a high security fingerprint verification system. *Pattern Recognition Letters*, 20(3):1371–1379, March 1999.
- [11] J. Kittler, M. Hatef, R. Duin, and J. Matas. On combining classifiers. *IEEE Trans. Pattern Analysis and Machine Intelligence*, 20(3), March 1998.
- [12] I. B. Perelle and L. Ehrman. An international study of human handedness: The data. *Behavior Genetetics*, 24(3):217–227, May 1994.
- [13] M. J. J. Scott, N. Niranjan, and R. W. Prager. Svm-based speaker verification algorithm for match-on-card. In John N. Carter and Mark S. Nixon, editors, *BMVC*. British Machine Vision Association, 1998.
- [14] R. Snelick, U. Uludag, A. Mink, M. Indovina, and A. Jain. Large scale evaluation of multimodal biometric authentication using state-of-the-art systems. *IEEE Trans. Pattern Analysis and Machine Intelligence*, 27(3):450–455, March 2005.
- [15] E. Tabassi, G. W. Quinn, and P. Grother. When to fuse two biometrics. In Proceedings of IEEE Conference on Computer Vision and Pattern Recognition. Workshop on Biometrics, June 2006. See http://fingerprint.nist.gov/minexII/CVPR06contingentfusion.pdf.

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent

A Hardware used

The testing software used on the NIST test systems is comprised of several layers: The NIST test driver; the PC/SC library; the PC/SC daemon; and the USB device drivers. The NIST test driver is part of the BIOMAPP project, described above. The operating system used was RedHat Enterprise Linux 4.

The PC/SC software used is part of the M.U.S.C.L.E. (www.linuxnet.com) project developing smartcard solutions for the Linux, OS-X, and Solaris operating systems. Many Linux distributions include the pcsclite package, comprising the PC/SC library and daemon. The smartcard reader driver used was the generic CCID driver. We initially used version 1.3.7 of the pcsc-lite driver (the default under Redhat 5) but migrated to version 1.4.0 after it was found that the older version added a nearly constant delay to all APDU calls. The newer version was used for all times reported herein.

Testing was done on dual-CPU Intel Xeon based blade computers, running at 2.80 GHz. Each system has 2G of RAM. The smartcard reader is the SCR 335 produced by SCM Microsystems, with a USB interface, and is CCID compliant. This reader supports T=0 and T=1 protocols, 7816 Class A and AB cards, up to 8 MHz.

Note that in Phase III (2009) the PC/SC library had upgraded from version 1.4.0 to 1.5.2 because the operating system had been updated, Redhat 5 vs. 4. While, the hardware was identical throughout, the time for all operations increased by about 0.005 seconds. This is evident in Figure 3(b) for the MX2N - MX2T implementations. We consider that this kind of systematic error will be an operational reality unless specific regression tests are performed after an update.

B Audit information

Study	MINEX II PHASE II		
Report generated	Thu May 21 13:34:01 2009		
Report name	minex_report.tex		
Report last modified	Thu May 21 13:33:57 2009		
Report MD5 hexadecimal	5bcb415de0382029cf6003df67e5b20b		
NIST contact	minexII@nist.gov		

MX2E = Sagem Morpho MX2J = Oberthur / id3 MX2O = Gemalto / Innovatrix MX2S = Gemalto / Micro Packs MX2G = Oberthur / id3 MX2K = Oberthur / id3 MX2P = Oberthur / id3 MX2T = Gemalto / Cogent